

INSTALLATION MANUAL

VRV[®]-S System Air Conditioner

MODEL

RXLA36AAVJU
RXLA48AAVJU

Installation manual English

Please visit <http://www.daikinac.com/content/resources/manuals> for the most current version of installation instructions and service manual. In the event of conflicting information, the online contents are to be used.

Veillez visiter <http://www.daikinac.com/content/resources/manuals> pour obtenir la version la plus récente des instructions d'installation et du manuel de service. En cas de conflit d'informations, le contenu en ligne est à privilégier.

Visite <http://www.daikinac.com/content/resources/manuals> para obtener la versión en español de las instrucciones de instalación y del manual de servicio. En caso de información contradictoria, se utilizarán los contenidos en línea.




figure 1




figure 2




figure 3




figure 4




figure 5




figure 6




figure 7




figure 8




figure 8




figure 9

figure 10

figure 11





figure 12




figure 13




figure 14




figure 15




figure 17




figure 16




figure 18




figure 19




figure 21




figure 20




figure 22




figure 23




figure 24




figure 25




figure 26




figure 27

CONTENTS

1. SAFETY CONSIDERATIONS 1

2. INTRODUCTION..... 3

2-1. Combination 3

2-2. Standard operation limit 3

2-3. Standard supplied accessories 3

2-4. Option accessory 3

3. BEFORE INSTALLATION..... 3

4. SELECTING INSTALLATION SITE 3

5. PRECAUTIONS ON INSTALLATION 5

6. REFRIGERANT PIPING 6

6-1. Installation tools 6

6-2. Selecting piping material 6

6-3. Protection against contamination when installing pipes..... 6

6-4. Pipe connection..... 6

6-5. Connecting the refrigerant piping 6

6-6. Thermal insulation of piping 7

6-7. Pipe size selection 8

6-8. Refrigerant branch kit selection..... 8

6-9. Refrigerant piping length and height difference 9

6-10. How to calculate the additional refrigerant to be charged..... 9

6-11. Air tight test and vacuum drying..... 10

7. ELECTRIC WIRING 11

7-1. Wiring connection example for whole system 11

7-2. How to lay the power supply wiring and transmission wiring..... 11

7-3. How to connect the power supply wiring..... 12

7-4. Transmission wiring connection procedure 12

8. ADDITIONAL REFRIGERANT CHARGE 13

8-1. Before adding refrigerant 13

8-2. Checking the refrigerant tank..... 13

8-3. Adding refrigerant..... 13

9. POST-WORK CHECKS..... 13

10. TEST OPERATION 13

10-1. Power On–Check Operation 14

10-2. Temperature control operation checklist 15

11. ENERGY SAVING AND OPTIMUM OPERATION 15

11-1. Four main operation methods are available:..... 15



11-2. Several comfort settings are available in VRT control/VRT smart control..... 16

12. CAUTION FOR REFRIGERANT LEAKS 18

13. WIRING DIAGRAM 19


1. SAFETY CONSIDERATIONS


Refer also to the General Safety Considerations in the separate booklet.


	<p>Read the precautions in this manual carefully before operating the unit.</p>
 <p>Refrigerant Safety Group A2L</p>	<p>This appliance is filled with R32.</p>


Read these “SAFETY CONSIDERATIONS for Installation” carefully before installing air conditioning equipment. After completing the installation, make sure that the unit operates properly during the startup operation. Instruct the customer on how to operate and maintain the unit. Inform customers that they should store this Installation Manual with the Operation Manual and General Safety Considerations for future reference. Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electrical shock, fire, or explosion.


Meanings of **DANGER**, **WARNING**, **CAUTION**, and **NOTE** Symbols:


 **DANGER** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

 **WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

 **NOTE**..... Indicates situations that may result in equipment or property damage accidents only.

-  **DANGER**
- Refrigerant gas is heavier than air and replaces oxygen. A massive leak will result in oxygen depletion, especially in basements, and an asphyxiation hazard will result in serious injury or death.
 - Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding will result a severe shock hazard resulting in severe injury or death. Additionally, grounding to gas pipes will result a gas leak and potential explosion resulting in severe injury or death.
 - If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas will result in producing toxic gas if it comes into contact with fire. Exposure to this gas will result in severe injury or death.
 - After completing the installation work, check that the refrigerant gas does not leak throughout the system.
 - Do not install unit in an area where flammable materials are present due to risk of explosions that will result in serious injury or death.
 - Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation will result in injuries or death by suffocation.

-  **WARNING**
- Only personnel that have been trained to install, adjust, service, maintenance or repair (hereinafter, “service”) the equipment specified in this manual should service the equipment.
 - This equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Children should be supervised to ensure that they do not play with the equipment.
 - The manufacturer will not be responsible for any injury or property damage arising from improper supervision, service or service procedures.
 - If you service this unit, you assume responsibility for any injury or property damage which may result. In addition, in jurisdictions that require one or more licenses to service the equipment specified in this manual, only licensed personnel should service the equipment.
 - Improper supervision, installation, adjustment, servicing, maintenance or repair of the equipment specified in this manual, or attempting to install, adjust, service or repair the equipment specified in this manual without proper supervision or training may result in product damage, property damage, personal injury or death.
 - Do not bypass safety devices.
 - Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation could result in water leakage, electric shock, or fire.
 - When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, could result in oxygen deficiency.
 - Use only specified accessories and parts for installation work. Failure to use specified parts could result in water leakage, electric shocks, fire, or the unit falling.

- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength could result in the unit falling and causing injuries.
- Take into account strong winds, hurricanes, or earthquakes when installing. Improper installation could result in the unit falling and causing accidents.
- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state and national regulations. An insufficient power supply capacity or improper electrical construction could result in electric shocks or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation could result in fire.
- When wiring, position the wires so that the control box cover can be securely fastened. Improper positioning of the control box cover could result in electric shocks, fire, or the terminals overheating.
- Before touching electrical parts, turn off the unit.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odor.
- Comply with national gas regulations.
- This equipment can be installed with a Ground-Fault Circuit Interrupter (GFCI). Although this is a recognized measure for additional protection, with the grounding system in North America, a dedicated GFCI is not necessary.
- Securely fasten the unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit and could result in fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R32) such as air. Any presence of air or other foreign substance in the refrigerant circuit could result in abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion could result.
- That pipe-work including piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and be in compliance with national and local codes and standards, such as ASHRAE 15, ASHRAE 15.2, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. All field joints shall be accessible for inspection prior to being covered or enclosed.
- Insulate piping to prevent condensation.
- Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may result.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R32 in the system must be kept clean, dry, and tight.
 - (a) Clean and Dry - Foreign materials (including refrigerant oil or moisture) should be prevented from getting into the system.
 - (b) Tight - R32 does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection against harmful ultraviolet radiation. R32 can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation.

Read the chapter Refrigerant Piping and follow the procedures.
- The indoor unit is for R32. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Indoor units are for indoor installation only. Outdoor units are for outdoor installation only. When installing outdoor units indoors, be sure to provide the required ventilation in accordance with ASHRAE 15 and local standards and building codes.
- Do not install the heat pump in the following locations:
 - (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate and fall off and thus may result in water leakage.
 - (b) Where corrosive gas, such as sulfurous acid gas, is produced. Corroding copper pipes or soldered parts may result in refrigerant leakage.
 - (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
 - (d) Where flammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts may result in malfunctions, smoke, or fire. Instruct the customer to keep the area around the unit clean.

NOTE

- Install the power supply and transmission wires for the indoor and outdoor units at least 3.5 ft. (1 m) away from televisions or radios to prevent image interference or noise. Depending on the radio waves, a distance of 3.5 ft. (1 m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with other refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the other refrigerant and refrigerant oil are mixed in R32, the refrigerant result in deterioration.
- This air conditioner or heat pump is an appliance that should be installed such that it is not accessible to general public.
- As maximum allowable pressure is 580 psi (4.0 MPa), the wall thickness of field-installed pipes should be selected in accordance with the relevant local, state, and national regulations.

CAUTION

- Do not touch the switch with wet fingers. Touching a switch with wet fingers may result in electric shock.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not allow children to play on or around the unit or it may result in injury.
- The heat exchanger fins are sharp enough to cut, and may result in injury if improperly used. To avoid injury wear glove or cover the fins when working around them.
- Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor, and other refrigerant cycle parts. It may result in your hands getting burns or frostbite if you touch the refrigerant pipes.

To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear proper gloves.
- Install drain piping to proper drainage. Improper drain piping may result in water leakage and property damage.

Codes and Regulations

This product is designed and manufactured to comply with national codes. Installation in accordance with such codes and/or prevailing local codes/regulations is the responsibility of the installer. The manufacturer assumes no responsibility for equipment installed in violation of any codes or regulations. Rated performance is achieved after 20 hours of operation.

2. INTRODUCTION

1. This series uses R32 refrigerant. Be absolutely sure to comply with "6. REFRIGERANT PIPING", exercise caution to prevent impurities from entering R32 (mineral oils and water).
2. The indoor unit must use R32. See the catalog for indoor unit models which can be connected. (The system is not compatible with other refrigerants.)
3. The power supply of this series is single-phase, 208/230V, 60Hz.

2-1 Combination

The indoor units can be installed in the following range.

- **Be sure to connect a dedicated indoor unit. See the catalog for indoor unit models which can be connected.**
 - Total capacity/quantity of indoor units
- | (Outdoor unit) | (Total capacity of indoor units) | (Total quantity of indoor units) |
|------------------|----------------------------------|----------------------------------|
| RXLA36 type..... | 18.0-46.8 MBh
5.3-13.7 kW | 6 units |
| RXLA48 type..... | 24.0-62.4 MBh
7.0-18.3 kW | 8 units |

2-2 Standard operation limit


Normal operation

The figures below assume following operating conditions for indoor and outdoor units:

Equivalent pipe length..... 25 ft. (7.6 m)
Level difference..... 0 ft. (0 m)

Cooling

Heating



- Range for operation
- Range for pull down operation
- Range for warming up operation

2-3 Standard supplied accessories

Make sure that the accessories shown below are all present. (The accessories can be found behind the front panel.)

Name	Operation manual	Clamp	Conduit mounting plate	
Quantity	1	4 pcs.	2 pcs.	2 pcs.
Shape				

Name	Insulation tube		Installation manual	General safety considerations
Quantity	1 pc.	1 pc.	1	1
Shape	 (Large)	 (Small)		

(Refer to figure 1)

1. Accessories
2. Screw for front panel
3. Front panel

2-4 Option accessory

- **Refrigerant branching kit**

REFNET joint	KHRP26A22T9/KHRP26A22TA
REFNET header	KHRP26M22H9/KHRP26M22HA KHRP26M33H9/KHRP26M33HA

See "6. REFRIGERANT PIPING" for details on how to connect refrigerant branch kits and how many are needed.

3. BEFORE INSTALLATION

<Transporting the Unit>

As shown in figure 2, move the unit slowly. (Take care not to let hands or other objects come in contact with rear fins.)

(Refer to figure 2)

1. Air outlet grille
2. Intake hole
3. Corner
4. Outdoor unit
5. Handle
6. Front
7. Rear
8. Always hold the unit by the corners, as holding it by the side intake holes on the casing may cause them to deform.

Use only accessories and parts which are of the designated specification when installing.

4. SELECTING INSTALLATION SITE

(1) Select an installation site where the following conditions are satisfied and that meets with your customer's approval.

- Places which are well-ventilated.
- Places where the unit does not bother next-door neighbors.
- A location where small animals will not make nests in the unit.
- Safe places which can withstand the unit's weight and vibration and where the unit can be installed level.
- A locations where there is enough space to install the unit.
- Places where the indoor and outdoor unit's piping and wiring lengths come within the allowable ranges.
- A location where there is no risk of flammable gas leaking.

(2) If the unit is installed in a location where it might be exposed to strong wind, install as per figure 3.

- 11 mph (5 m/s) or higher winds blown against the outdoor unit's exhaust cause a deterioration in the system performance. High winds force re-circulation of the exhaust air into the inlet, which is known to cause the following effects:
 - Reduction in performance.
 - Increased frost formation in heating mode.
 - System shut down due to increased pressures.
- If very strong wind blows continuously on the air outlet side of the outdoor unit, the fan may turn in reverse at high speed and break, so install as per figure 3.

(Refer to figure 3)

1. Turn the air outlet side toward the building's wall, fence or windbreak screen.
2. Air inlet grille
3. Ensure there is enough space for installing the unit.
4. Set the outlet side at a right angle to the direction of the wind.
5. Strong wind
6. Blown air

(3) When installing the unit in a place frequently exposed to snow, pay special attention to the following:

- Install the outdoor unit on a stand (field supply), so that the bottom frame is more than 20 in. (500 mm) higher than the expected snow fall to prevent it from being covered by snow.
- Attach a snow hood (field supply) and a snow visor (field supply).
- Avoid installation at the place where a snowdrift is generated.
- Further, perform the following countermeasures, since there is risk that the drain water produced at the defrost operation freezes.
- Install the outdoor unit so that its bottom place level has a sufficient height from foundation level, so that ice does not grow at the lower surface of the bottom place of the outdoor unit. (Recommended clearance: 20 in. (500 mm) or more)
- In areas where the outside air temperature drops below 32°F (0°C) for more than 12 hours continuously, install a drain-pan heater (optional accessory) on the bottom frame to prevent the drain from freezing.
- An optional drain pan heater is available when the unit is installed in a climate where the drain may freeze.
- The installer should use their local knowledge to determine if this accessory is necessary to prevent the drain from freezing.
- Do not use a concentrated drain plug (field supply).
(If a drain plug and/or drain pipe are/is used, there is a risk of freezing.)
- If there is a problem with drain dripping from the bottom frame drain, set up a roof (field supply) below the outdoor unit, or enact other countermeasures.
- Remove the rear inlet grille to prevent snow from accumulating on the rear fins.

(4) When there is possibility of short-circuit depending on the ambient situation, use the wind direction adjusting plate (optional accessory).

(5) The refrigerant gas (R32) is a safe, non-toxic but mildly flammable. If it leaks into the room, the concentration may exceed tolerance levels, especially in small rooms, so steps need to be taken to prevent refrigerant leakage. See the equipment design reference for details.

(6) Inverter-type air conditioners sometimes cause static in other electrical appliances.

When selecting an installation location, make sure the air conditioner and all wiring are sufficiently far away from radios, computers, stereos, and other appliances, as shown in figure 4. Particularly for locations with weak reception, ensure there is a distance of at least 9.8 ft. (3 m) for indoor remote controllers, place power supply wiring and transmission wiring in conduits, and ground the conduits. Use non-shielded wire for transmission wiring.

(Refer to figure 4)

1. Indoor unit
2. Fuse/Breaker
3. Remote controller
4. Personal computer or radio

(7) Space needed for installation

<Precautions when installing units in series>

- The direction for field piping is either forward or down when installing units in series, as shown in the figure(5~10).
- If the piping is brought out from the back, the outdoor unit will require at least 10 in. (250 mm) from its right side.

(7)-1 IN CASE OBSTACLES EXIST ONLY IN FRONT OF THE AIR INLET

When nothing is obstructing the top

1. Installation of single unit
 - In case obstacles exist only in front of the air inlet **(Refer to figure 5-[1])**
 - In case obstacles exist in front of the air inlet and on both sides of the unit **(Refer to figure 5-[2])**
2. In case of installing multiple units (2 units or more) in lateral connection per row
 - In case obstacles exist in front of the air inlet and on both sides of the unit **(Refer to figure 5-[3])**

When something is obstructing the top

1. Installation of single unit
 - In case obstacles exist only in front of the air inlet **(Refer to figure 6-[1])**
 - In case obstacles exist in front of the air inlet and on both sides of the unit **(Refer to figure 6-[2])**
2. In case of installing multiple units (2 units or more) in lateral connection per row
 - In case obstacles exist in front of the air inlet and on both sides of the unit **(Refer to figure 6-[3])**

(7)-2 IN CASE OBSTACLES EXIST IN FRONT OF THE OUTLET SIDE

When nothing is obstructing the top

1. Installation of single unit **(Refer to figure 7-[1])**
2. In case of installing multiple units (2 units or more) in lateral connection per row **(Refer to figure 7-[2])**

When something is obstructing the top

1. Installation of single unit **(Refer to figure 7-[3])**
2. In case of installing multiple units (2 units or more) in lateral connection per row **(Refer to figure 7-[4])**

(7)-3 IN CASE OBSTACLES EXIST IN FRONT OF BOTH THE AIR INLET AND OUTLET SIDES

Pattern 1: Where obstacle in front of the air outlet is higher than the unit.
(There is no height limit for obstructions on the intake side.)

When nothing is obstructing the top

1. Installation of single unit **(Refer to figure 8-[1])**
2. In case of installing multiple units (2 units or more) in lateral connection per row **(Refer to figure 8-[2])**

When something is obstructing the top

1. Installation of single unit **(Refer to figure 8-[3])**
Relation of dimensions of H, A, and L are shown in the table below.
in.(mm)

	L	A
L ≤ H	0 < L ≤ 1/2H	30(750)
	1/2H < L ≤ H	40(1000)
H < L	Set the frame to be L ≤ H	

Note)

Close the area under the frame so the outlet air does not bypass there.

2. Series installation (up to two units) **(Refer to figure 8-[4])**
Relation of dimensions of H, A, and L are shown in the table below.
in.(mm)

	L	A
L ≤ H	0 < L ≤ 1/2H	40(1000)
	1/2H < L ≤ H	50(1250)
H < L	Set the frame to be L ≤ H	

Note)

1. Close the area under the frame so the outlet air does not bypass there.
2. No more than two units can be installed in series.

Pattern 2: Where obstacles in front of the air outlet is lower than the unit.
(There is no height limit for obstructions on the intake side.)

When nothing is obstructing the top

1. Installation of single unit (**Refer to figure 8-[5]**)
2. In case of installing multiple units (2 units or more) in lateral connection per row (**Refer to figure 8-[6]**)
Relation of dimensions of H, A, and L are shown in the table below.
in.(mm)

L	A
$0 < L \leq 1/2H$	10(250)
$1/2H < L \leq H$	12(300)

When something is obstructing the top

1. Installation of single unit (**Refer to figure 8-[7]**)
Relation of dimensions of H, A, and L are shown in the table below.
in.(mm)

	L	A
L ≤ H	$0 < L \leq 1/2H$	4(100)
	$1/2H < L \leq H$	8(200)
H < L	Set the frame to be L ≤ H	

Note)

Get the lower part of the frame sealed so that air from the outlet does not bypass.

2. Series installation (up to two units) (**Refer to figure 8-[8]**)
Relation of dimensions of H, A, and L are shown in the table below.
in.(mm)

	L	A
L ≤ H	$0 < L \leq 1/2H$	10(250)
	$1/2H < L \leq H$	12(300)
H < L	Set the frame to be L ≤ H	

Note)

1. Get the lower part of the frame sealed so that air from the outlet does not bypass.
2. Only two units at most can be installed in series.

(7)-4 IN CASE OF STACKED INSTALLATION

- (1) In case obstacles exist in front of the outlet side (**Refer to figure 9-[1]**)
- (2) In case obstacles exist in front of the air inlet (**Refer to figure 9-[2]**)

Note)

1. No more than two units should be stacked.
2. If there is a danger of water from the drain falling on the lower outdoor unit and freezing, install a roof (field supply) as shown in the figure 9.
3. To prevent the formation and growth of ice in the bottom frame of the 2nd level outdoor unit, install the outdoor unit so that the bottom frame will be sufficiently higher than the lower outdoor unit. (It is recommended to leave 19.6 in. (500 mm) or more)
4. Shut off the area between the upper outdoor unit and the lower outdoor unit so that outlet air does not bypass.

(7)-5 IN CASE OF MULTIPLE-ROW INSTALLATION (FOR ROOF TOP USE, ETC.)

1. In case of installing one unit per row (**Refer to figure 10-[1]**)
2. In case of installing multiple units (2 units or more) in lateral connection per row (**Refer to figure 10-[2]**)
Relation of dimensions of H, A, and L are shown in the table below.
in.(mm)

	L	A
L ≤ H	$0 < L \leq 1/2H$	10(250)
	$1/2H < L \leq H$	12(300)
H < L	Installation impossible.	

5. PRECAUTIONS ON INSTALLATION

- Before installation, make sure the unit is level and the foundation is sturdy enough to prevent vibration and noise.
- Fasten the unit in place using 4 foundation bolts M12 or equivalent. It is best to screw in the foundation bolt until their length remains 13/16 in. (20 mm) above the foundation surface.

(Refer to figure 11)

1. Diagram of lower surface

<Drain pipe installation>

- Locations where drain water from the outdoor unit might be a problem.

In such locations, for example, where the drain water might drip onto passers by, lay the drain pipe using the separately sold drain plug and seal up the drain holes in the bottom frame. For details, please contact your dealer.

In case of installing the outdoor unit in cold climates, do not take this centralized drainage way. Otherwise, drain pipe freeze-up and ice build-up on the bottom frame may occur.

- When laying the drain pipe, at least 4 in. (100 mm) from the bottom of the outdoor unit is needed.
- Make sure the drainage works properly.
(Watch out for water leaks if piping is brought out the bottom.)

(Refer to figure 12)

1. Drain plug
2. 4 tabs
3. Drain receiver
4. Insert the drain receiver into the drain plug and hook the tabs.
5. Bottom frame drain hole
6. (1) Insert the drain plug through the drain hole in the bottom frame shown in figure 13.
(2) Turn the drain plug along the guides until it stops (approx. 40°).
7. Guide

(Refer to figure 13)

1. Air outlet side
2. Diagram of lower surface
3. Drain hole (For plug)
4. Drain hole

6. REFRIGERANT PIPING

- Do not allow anything other than the designated refrigerant to get mixed into the refrigerant cycle, such as air, nitrogen, etc. If any refrigerant gas leaks while working on the unit, ventilate the room thoroughly right away.
- Use R32 only when adding refrigerant.

6-1 Installation tools

CAUTION

Make sure to use speciality tools to withstand the pressure and to prevent foreign materials from mixing into the system.

Gauge manifold Charge hose	<ul style="list-style-type: none"> Make sure to use installation tools that are exclusively made for R32 installations to withstand the pressure and to prevent foreign materials (e.g., mineral oils such as SUNISO and moisture) from mixing into the system.
Vacuum pump	<ul style="list-style-type: none"> Use a 2-stage vacuum pump with a non-return valve. Make sure the pump oil does not flow backward into the system while the pump is not working. Use a vacuum pump which can evacuate to 500 microns.

6-2 Selecting piping material

CAUTION

Piping and other pressure containing parts shall comply with the applicable legislation and shall be suitable for refrigerant. Use phosphoric acid deoxidized seamless copper for refrigerant.

CAUTION



- All field piping must be installed by a licensed refrigeration technician and must comply with relevant local and national regulations.
- After piping work is complete, do not under any circumstances open the stop valve until **7. ELECTRIC WIRING** on page 11 and **9. POST-WORK CHECKS** on page 13 are complete.
- Do not use flux when brazing copper-to-copper refrigerant piping. Use phosphor copper brazing filler alloy (BCuP) which does not require flux. Flux has extremely negative effect on refrigerant piping systems. For instance, if the chlorine based flux is used, it will cause pipe corrosion or, in particular, if the flux contains fluorine, it will damage the refrigerant oil.
- Use only pipes which are clean inside and outside and which do not accumulate harmful sulfur, oxidants, dirt, cutting oils, moisture, or other contamination. (Foreign materials inside pipes including oils for fabrication must be 0.14 gr/10 ft. (30 mg/10 m) or less.)
- Use the following items for the refrigerant piping.
Material: Jointless phosphor-deoxidized copper pipe.
Size: See **6-7 Pipe size selection**.
Thickness: Select a thickness for the refrigerant piping which complies with national and local laws.
- Install the refrigerant branch kit while observing the following condition and referring to the installation manual offered as an accessory of the kit.

(Refer to figure 14)

- Install the REFNET joint so it splits horizontally or vertically.
- Horizontal surface
- A-arrow view
- $\pm 30^\circ$ or less
- Level
- Vertical is also OK
- Install the REFNET header so that it splits horizontally.
- B-arrow view

6-3 Protection against contamination when installing pipes

- Cover the ends of pipe to prevent moisture, dirt, dust, etc. from entering the piping.
- Exercise caution when passing copper piping through the through-holes and when passing them out to the outside.

Place	Installation	Protection method
	More than a month	Pinch the pipe
	Less than a month	Pinch or tape the pipe
	Regardless of the period	

6-4 Pipe connection

- See “Stop valve operation procedure” in “**6-11 Air tight test and vacuum drying**” regarding handling of the stop valve.
- Only use the flare nuts included with the unit. Using different flare nuts may cause the refrigerant to leak.
- Be sure to perform a nitrogen blow when brazing.** (Brazing without performing nitrogen replacement or releasing nitrogen into the piping will create large quantities of oxidized film on the inside of the pipes, adversely affecting valves and compressors in the refrigerating system and preventing normal operation.)

(Refer to figure 15)

- Refrigerant pipe
- Location to be brazed
- Regulator
- Nitrogen
- Manual valve
- Taping

6-5 Connecting the refrigerant piping

- The local field piping is connectable in four directions.

(Refer to figure 16)

- Front panel
- Pipe outlet panel
- Backward
- Sideways
- Downward
- Pipe outlet panel screw
- Forward
- Screw for front panel

- When connecting the pipings downward, remove the knockout by making four holes in the middle on the each side of the knockout with a drill.**

(Refer to figure 17)

- Drill
- Center area around knockout hole
- Knockout hole
- Slit

- After knocking out the knockout hole, it is recommended to apply repair paint to the edge and the surrounding end surfaces to prevent rusting.

(Refer to figure 18)

- Bottom frame
- Field piping

Limitations when using existing pipes.

When installing VRV-S use specified pipe diameter sizes and insulate both gas and liquid lines. An exception to this would be in a replacement application where existing piping could be used with the following requirements:

- Ensure that piping is thoroughly cleaned.
- Observe the piping size requirements per section **6-7 Pipe size selection**.
- Piping for both liquid and gas pipes should be insulated.
- In installations where existing refrigerant pipes are being used; and the pipes are not accessible to the installer, ensure that all visible


piping is insulated. The refrigerant pipes between the outdoor unit and wall must be insulated if any portion of the un-accessible liquid pipe cannot be insulated. Failure to follow the instruction may lead to damage due to sweating and cause compressor damage and void warranty.


NOTE 

Cutting out the two slits makes it possible to install as shown in figure 18. (Use a metal saw to cut out the slits.)

<Precautions when connecting pipes>

- Please refer to the table below for the dimensions for processing flares.
- When connecting the flare nut, coat the flare both inside and outside with refrigerating machine oil and initially tighten by hand 3 or 4 turns before tightening firmly.
- Please refer to the table below for the tightening torque. (Too much tightening will end up in splitting of the flare.)

Pipe size [in. (mm)]	Tightening torque [lbf-ft. (N-m)]	Dimension for processing flare A [in. (mm)]	Flare shape [in. (mm)]
φ 3/8 (9.5)	24.1~29.4 (32.7~39.9)	0.504~0.520 (12.8~13.2)	
φ 5/8 (15.9)	45.6~55.6 (61.8~75.4)	0.760~0.776 (19.3~19.7)	
φ 3/4 (19.1)	71.7~87.5 (97.2~118.6)	0.929~0.945 (23.6~24.0)	



- If a torque wrench is not available, there is a place where the tightening torque will suddenly increase if a normal wrench is used to tighten the flare nut.

From that position, further tighten the flare nut the angle shown below.

Pipe size [in. (mm)]	Further tightening angle	Recommended arm length of tool [in. (mm)]
φ 3/8 (9.5)	60°~ 90 °	Approx. 7 7/8 (200)
φ 5/8 (15.9)	30°~ 60°	Approx. 11 13/16 (300)
φ 3/4 (19.1)	20°~ 35°	Approx. 17 11/16 (450)

- After all the piping has been connected, use nitrogen to perform a gas leak check.

Precautions for connecting pipes

- Be careful not to let the field piping come into contact with the compressor terminal cover. Adjust the height of the insulation material on liquid pipe when it has the possibility of getting in contact with the terminal. Also make sure that the field piping does not touch the mounting bolt of the compressor.

(Refer to figure 19)

1. Compressor
 2. Corking, etc.
 3. Insulation material
 4. Bolts
 5. Field piping
- If installing the outdoor unit higher than the indoor unit, caulk the space around insulation and tubes because condensation on the check valve can seep through to the indoor unit side.

[Preventing foreign objects from entering]

- Plug the pipe through-holes with putty or insulating material (procured locally) to stop up all gaps, as shown in figure 20. (Figure 20 indicates the forward case. Do the same in case of other directions.) Insects or small animals entering the outdoor unit may cause a short in the control box.

(Refer to figure 20)

1. Putty or insulating material
2. (field supply)

6-6 Thermal insulation of piping

- Highly recommended to insulate the field piping (liquid and gas) and the refrigerant branch kit. (Not insulating them may cause leaking.)
- The insulation dimension is recommended as following:


Ambient temperature: 86°F (30°C), humidity : Below 80% RH	Ambient temperature: 86°F (30°C), humidity : 80% RH and above
Minimum thickness : 9/16 in. (15 mm)	Minimum thickness : 3/4 in. (20 mm)

- When using commercial copper pipes and fittings, observe the following:
 - a) Insulation of pipes should be done after performing air tight test and vacuum drying.
 - b) Heat transfer rate: 0.024 to 0.030 BTU/fth°F (0.041 to 0.052 W/Mk (0.035 to 0.045 kcal/MBh°C))
 - c) Be sure to use insulation that is designed for use with HVAC Systems.
 - d) The highest temperature that the gas-side piping can reach is around 248°F (120°C), so be sure to use insulating material which is sufficiently resistant to this temperature.

CAUTION
 For local insulation, be sure to insulate all the way to the pipe connections inside the unit.
 Exposed piping may cause leaks or burns on contact.

6-7 Pipe size selection


Determine the proper size using the following tables and reference figure (only for indication).



- 1 Outdoor unit
- 2 Refrigerant branch kits
- 3-1~3-4 VRV indoor units
- A Piping between outdoor unit and (first) refrigerant branch kit
- B-1, B-2 Piping between refrigerant branch kits
- C-1~C-4 Piping between refrigerant branch kit and indoor unit

A: Piping between outdoor unit and (first) refrigerant branch kit

When the equivalent pipe length between outdoor unit and the furthest indoor unit is 295 ft. (90 m) or more (b+d), the size of the main gas pipe (b) must be increased (size-up). If the recommended gas pipe (size-up) is not available, you must use the standard size (which might result in a small capacity decrease).



- a Outdoor unit
- b Main gas pipe (increase piping size if length b+d ≥ 295 ft. (90 m))
- c First refrigerant branch kit
- d Piping between indoor unit and first refrigerant branch kit
- e Furthest indoor unit

Outdoor unit capacity type	Piping outer diameter size		
	Gas pipe		Liquid pipe [in. (mm)]
	Standard [in. (mm)]	Size-up (only 'b') [in. (mm)]	
RXLA36,48 type	φ 5/8 (15.9)	φ 3/4 (19.1)	φ 3/8 (9.5)

B: Piping between refrigerant branch kits

Choose from the following table in accordance with the indoor unit total capacity type, connected downstream. Do not let the connection piping exceed the refrigerant piping size chosen by the general system model name.

Indoor unit capacity index	Piping outer diameter size	
	Gas pipe [in. (mm)]	Liquid pipe [in. (mm)]
0 ≤ x ≤ 54	φ 5/8 (15.9)	φ 3/8 (9.5)

Example: Downstream capacity for B-1 = capacity index of unit 3-1 + capacity index of unit 3-2

C: Piping between refrigerant branch kit and indoor unit

Use the same diameters as the connections (liquid, gas) on the indoor units. The diameters of the indoor units are as follows:

Indoor unit capacity type	Piping outer diameter size	
	Gas pipe [in. (mm)]	Liquid pipe [in. (mm)]
07 • 09 • 12 • 15 • 18 type	φ 1/2 (12.7)	φ 1/4 (6.4)
24 • 30 • 36 • 48 • 54 type	φ 5/8 (15.9)	φ 3/8 (9.5)

6-8 Refrigerant branch kit selection

For piping example, see "6-7 Pipe size selection".

REFNET joint at first branch (counting from outdoor unit)

When using REFNET joints at the first branch counted from the outdoor unit side, choose from the following table in accordance with the capacity of the outdoor unit. **Example:** REFNET joint A→B-1.

Outdoor unit capacity type	Refrigerant branch kit
RXLA36,48 type	KHRP26A22T9/KHRP26A22TA

REFNET joints at other branches

For REFNET joints other than the first branch, select the proper branch kit model based on the total capacity index of all indoor units connected after the refrigerant branch. **Example:** REFNET joint B-1→C-1.

Indoor unit capacity index	Refrigerant branch kit
<54	KHRP26A22T9/KHRP26A22TA


REFNET headers

Concerning REFNET headers, choose from the following table in accordance with the total capacity of all the indoor units connected below the REFNET header.

Indoor unit capacity index	Refrigerant branch kit
<54	KHRP26M22H9/KHRP26M22HA (Max. 4 branch) KHRP26M33H9/KHRP26M33HA (Max. 8 branch)

NOTE

The piping branch by REFNET joints is possible in the downstream of REFNET headers. Indoor unit total capacity at REFNET joints according to the REFNET header are as follows.




REFNET Header	Indoor unit total capacity at REFNET joint
KHRP26M22H9 KHRP26M22HA	<18
KHRP26M33H9 KHRP26M33HA	

6-9 Refrigerant piping length and height difference

Connection with only VRV indoor units


The piping lengths and height differences must comply with the following requirements.

Example 1: in case of REFNET joints only




Indoor units (1-8)

Example 2: in case of REFNET joints and header



Indoor units (1-8)

Example 3: in case of REFNET header only



Indoor units (1-8)

Requirement	Limit	
Maximum actual piping length <ul style="list-style-type: none"> Example 1, unit 8: $a+b+c+d+e+f+g+p \leq \text{Limit}$ Example 2, unit 6: $a+b+h \leq \text{Limit}$ Example 3, unit 8: $a+i \leq \text{Limit}$ 	394 ft. (120 m)	
Maximum equivalent piping length*	492 ft. (150 m)	
Maximum total piping length <ul style="list-style-type: none"> Example 1: $a+b+c+d+e+f+g+h+i+j+k+l+m+n+p \leq \text{Limit}$ 	984 ft. (300 m)	
Maximum length first branch kit-indoor unit <ul style="list-style-type: none"> Example 1, unit 8: $b+c+d+e+f+g+p \leq \text{Limit}$ Example 2, unit 6: $b+h \leq \text{Limit}$ Example 2, unit 8: $i+k \leq \text{Limit}$ Example 3, unit 8: $i \leq \text{Limit}$ 	131 ft. (40 m)	
Maximum height difference outdoor-indoor	Outdoor higher than indoor • Examples: $H1 \leq \text{Limit}$	164 ft. (50 m)
	Outdoor lower than indoor	131 ft. (40 m)
Maximum Indoor to Indoor height difference <ul style="list-style-type: none"> Examples: $H1 \leq \text{Limit}$ 	49 ft. (15 m)	

* Assume equivalent piping length of REFNET joint=1.6 ft. (0.5 m), REFNET header=3.2 ft. (1 m) and L joints in the table below. (for calculation purposes of equivalent piping length, not for refrigerant charge calculations).

Pipe Size * [in.(mm)]	Equivalent Piping Length of L Joints [in.(m)]
φ 1/4 (6.4)	6-1/4 (0.16)
φ 3/8 (9.5)	7-1/8 (0.18)
φ 1/2 (12.7)	7-7/8 (0.20)
φ 5/8 (15.9)	9-7/8 (0.25)
φ 3/4 (19.1)	13-3/4 (0.35)

* When the equivalent piping length in cooling operation is calculated, the gas pipe size is selected. When the equivalent piping length in heating operation is calculated, the liquid pipe size is selected.

6-10 How to calculate the additional refrigerant to be charged

⚠ WARNING

- The maximum allowable total refrigerant amount is determined based on the smallest room being served by the system.
- See "General Safety Considerations" in the separate booklet to determine the maximum allowable total refrigerant amount.

Note down the amount of additional refrigerant that is calculated here, for later use on the additional refrigerant charge label on the units.

Additional refrigerant to be charged R (lbs, kg)

R should be rounded off in units of 0.1lbs(kg)

$$R = \left(\frac{\text{Total length (ft.) of liquid piping size at } \phi 3/8''}{\phi 3/8''} \right) \times 0.035 + \left(\frac{\text{Total length (ft.) of liquid piping size at } \phi 1/4''}{\phi 1/4''} \right) \times 0.013 + \left(\frac{\text{Refrigerant adjustment by connected indoor unit type (FXTA type) }^{*1}}{\text{type (FXTA type) }^{*1}} \right)$$

*1 Additional refrigerant must be charged when connecting an FXTA type indoor unit. Refer to the installation manual of the indoor unit for the amount of additional refrigerant adjustment.

Example for refrigerant branch using REFNET joint and REFNET header

a: φ3/8" × 100 ft.	d: φ3/8" × 40 ft.	g: φ1/4" × 30 ft.	j: φ1/4" × 30 ft.
b: φ3/8" × 30 ft.	e: φ1/4" × 30 ft.	h: φ1/4" × 60 ft.	k: φ1/4" × 30 ft.
c: φ3/8" × 30 ft.	f: φ1/4" × 30 ft.	i: φ3/8" × 30 ft.	

$$R = \frac{230 \times 0.035}{a+b+c+d+i} + \frac{210 \times 0.013}{e+f+g+h+j+k} = 10.78 \Rightarrow 10.8 \text{ lbs}$$

$$R = \left(\frac{\text{Total length (m) of liquid piping size at } \phi 9.5}{\phi 9.5} \right) \times 0.053 + \left(\frac{\text{Total length (m) of liquid piping size at } \phi 6.4}{\phi 6.4} \right) \times 0.020 + \left(\frac{\text{Refrigerant adjustment by connected indoor unit type (FXTA type) }^{*1}}{\text{type (FXTA type) }^{*1}} \right)$$

*1 Additional refrigerant must be charged when connecting an FXTA type indoor unit. Refer to the installation manual of the indoor unit for the amount of additional refrigerant adjustment.

Example for refrigerant branch using REFNET joint and REFNET header

a: φ9.5 × 30 m	d: φ9.5 × 12 m	g: φ6.4 × 9 m	j: φ6.4 × 9 m
b: φ9.5 × 9 m	e: φ6.4 × 9 m	h: φ6.4 × 18 m	k: φ6.4 × 9 m
c: φ9.5 × 9 m	f: φ6.4 × 9 m	i: φ9.5 × 9 m	

$$R = \frac{69 \times 0.053}{a+b+c+d+i} + \frac{63 \times 0.020}{e+f+g+h+j+k} = 4.91 \Rightarrow 4.9 \text{ kg}$$

6-11 Air tight test and vacuum drying

After doing the piping, perform the following inspections.

Air tight test

Be sure to use nitrogen gas. (See the figure ("Stop valve operation procedure") for the location of the service port.)

[Procedure]

Pressurize from the liquid pipes and gas pipes to 580 psi (4.0 MPa).

If there is not pressure drop over the next 24 hours, the equipment has passed the test.

If the pressure drops, check for leakage positions. (Confirm that there is no leakage, then release nitrogen.)

Vacuum drying

Use a vacuum pump that can create a vacuum down to at least 500 microns.

[Procedure]

Operate the vacuum pump for **at least 2 hours** from **both the liquid and gas pipes** and decrease the pressure to at least 500 microns.

Leave at below 500 microns for at least 1 hour and make sure that the vacuum gauge does not rise. (If it does rise, there is either still moisture in the system or a leak.)

Cases where moisture might enter the piping (i.e., if doing work during the rainy season, if the actual work takes long enough that condensation may form on the inside of the pipes, if rain might enter the pipes during work, etc.)

After performing the vacuum drying for 2 hours, pressurize to 7.2 psi (0.05 MPa) (i.e., vacuum breakdown) with nitrogen gas, then depressurize down to at least 500 microns for an hour using the vacuum pump (vacuum drying). (If the pressure does not reach at least 500 microns even after depressurizing for at least 2 hours, repeat the vacuum breakdown - vacuum drying process.) Leave as a vacuum for 1 hour after that, and make sure the vacuum gauge does not rise.

(Refer to figure 21)

1. Decompression valve
2. Nitrogen
3. Vacuum pump
4. Valve (Open)
5. Charge hose
6. Stop valve service port
7. Indoor unit
8. Gas line stop valve (Close)
9. Liquid line stop valve (Close)
10. Indicates local procurement
11. Outdoor unit


NOTE

The stop valve must always be turned to "closed". Otherwise the refrigerant in the outdoor unit will pour out.


Stop valve operation procedure

Precautions when handling the stop valve

- The names of parts needed to operate the stop valve are shown in the figure below. The unit is shipped from the factory with the stop valve turned to the "closed" position.



- Since the side boards may be deformed if only a torque wrench is used when loosening or tightening flare nuts, always lock the stop valve with a wrench and then use a torque wrench.
- In cases where the unit is run in heating mode when the outside temperature is low or in other situations where the operating pressure might drop, seal the gas-side flare nut on the stop valve with silicon sealant or the like to prevent it from freezing.



Stop valve operation procedure


Have a hex wrench ready (size: 0.2 in. (4 mm) and 0.3 in. (6 mm)).

Opening the valve

1. Place the hex wrench on the valve stem and turn counter-clockwise.
2. Stop when the valve stem no longer turns. It is now open.


Close the valve

1. Place the hex wrench on the valve stem and turn clockwise.
2. Stop when the valve stem no longer turns. It is now closed.



Precautions for handling valve cap

- A seal is attached to the point indicated by the arrow. Take care not to damage it.



- Be sure to tighten the valve cap securely after operating the valves.

Liquid-side tightening torque	Gas-side tightening torque
10.0 ~ 12.2 ft-lbf	16.6 ~ 20.3 ft-lbf
13.5 ~ 16.5 N-m	22.5 ~ 27.5 N-m

Precautions for handling servicing port

- Use a push-rod-provided charging hose for operation.
- Be sure to tighten the valve cap securely after operation.
Tightening torque8.5 ~ 10.3 ft-lbf (10.8 ~ 14.7 N-m)

7. ELECTRIC WIRING

CAUTION

To the electrician

- Do not operate until refrigerant piping work is completed. (Failure to adhere by this caution may lead to irreparable compressor damage.)

7-1 Wiring connection example for whole system

- Electrical wiring work should be done by a certified professional.
- Means for full disconnection under overvoltage category III conditions must be incorporated in the fixed wiring according to national wiring rules.
- Follow the "Wiring diagram" label when carrying out any electrical wiring. Only proceed with wiring work after turning off all power.
- Always ground wires in accordance with relevant local and national regulations.
- Ground the indoor and outdoor units.
- Do not connect the ground wire to gas pipes, sewage pipes, lightning rods, or telephone ground wires.
 - Gas pipes:** can explode or catch fire if there is a gas leak.
 - Sewage pipes:** no grounding effect is possible if hard plastic piping is used.
 - Lightning rods and telephone ground wires:** dangerous when struck by lightning due to abnormal rise in electrical potential in the grounding.
- Use copper wire.
- When doing the electrical wiring, always shut off the power supply before working, and do not turn on the switch until all work is complete.
- This unit has an inverter, so it must be grounded in order to reduce noise and prevent it affecting other appliances, and also to release any electrical build-up in the unit case due to leaked current.
- Do not install a power-factor improving phase-advancing capacitor under any circumstances. (Not only will this not improve the power factor, but it might cause a fire.)
- Connect the wire securely using designated wire and fix it with attached clamp without applying external pressure on the terminal parts (terminal for power supply wiring, terminal for transmission wiring and ground terminal). See "7-3 How to connect the power supply wiring".
- Leftover wiring should not be wrapped and stuffed into the unit.
- Secure the wiring with the included clamp so that it does not come in contact with the piping or stop valve. (See "7-3 How to connect the power supply wiring".)

CAUTION

- Use a conduit for field wiring.
- Outside the unit, make sure the communication wiring (i.e. for the remote controller wire, between units, etc.) and the high voltage wiring do not pass near each other, **keeping them at least 2 in. (50 mm) apart**. Proximity may cause electrical interference, malfunctions, and breakage.
- Be sure to connect the power supply wiring to the power supply wiring terminal block and secure it as described in "7-3 How to connect the power supply wiring".
- Transmission wiring should be secured as described in "7-4 Transmission wiring connection procedure".
- Secure wiring with clamp (accessory) to avoid contact with piping.
- Make sure the wiring and the front panel do not stick up above the structure, and close the panel firmly.

(Refer to figure 22)

- Fuse/Breaker
- Power supply
- Outdoor unit
- 16V


- 208/230V
- Indoor unit
- Remote controller
- Ground wire

7-2 How to lay the power supply wiring and transmission wiring


Let the power supply wiring and transmission wiring with a conduit pass through one of the knockout holes on the front or side cover, and let the transmission wiring with a conduit pass through another knockout hole.

- For protection from uninsulated live parts, thread the power supply wiring and the transmission wiring through the included insulation tube and secure it with the included clamp.

<Power supply wiring (field supply)>




<Transmission wiring (field supply)>



Precautions about knockout holes

- Open the knockout holes with a hammer or the like.
- After knocking out the holes, we recommend you remove burrs in the knockout holes and paint the edges and areas around the edges using the repair paint to prevent rusting.
- When passing wiring through knockout holes, make sure there are no burrs, and protect the wiring with protective tape.




If small animals might enter the unit, block the knockout holes with an appropriate material (field supply).

(Refer to figure 23)


- Stop valve fixing plate
- Power supply wiring (including ground wire) or transmission wiring.
- Back of unit
- Knockout hole
- Side of unit
- Front of unit
- Terminal block
- Control Box

<Precautions when laying power supply wiring>

- Wiring of different thicknesses cannot be connected to the power supply terminal block.
(Slack in the power supply wiring may cause abnormal heat.)
- Use sleeve-insulated round pressure terminals for connections to the power supply terminal block. When none are available, connect wire of the same diameter to both sides, as shown in the figure.



Connect wires of the same gauge to both side. Do not connect wires of the same gauge to one side. Do not connect wires of different gauges.



Follow the instructions below if the wiring gets very hot due to slack in the power supply wiring.

- For wiring, use the designated power wire and connect firmly, then secure using the included clamping material to prevent outside pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screw may break it.

See the table below the tightening torque of the terminal screws.

Tightening torque (ft. lbf / N·m)		
M5	Power supply terminal	1.63~1.98 / 2.21~2.69
M5	Shield ground	2.36~2.88 / 3.20~3.90
M3.5	Transmission wiring terminal block	0.59~0.81 / 0.80~1.10

7-3 How to connect the power supply wiring



CAUTION

Attach a circuit breaker or fuse.

Model name	Phase and frequency	Voltage	Maximum overcurrent protective device	Minimum circuit ampacity
RXLA36 type	1~60Hz	208/230V	25A	24.8A
RXLA48 type	1~60Hz	208/230V	35A	34.6A



CAUTION

- The wiring should be selected in compliance with local laws and regulations. See the table above.
- Always turn off the power before doing wiring work.
- Grounding should be done in compliance with local laws and regulations.
- As shown in figure 24, when connecting the power supply wiring to the power supply terminal block, be sure to clamp securely.
- Once wiring work is completed, check to make sure there are no loose connections among the electrical parts in the control box.

(Refer to figure 24)

- Stop valve fixing plate
- Clamp (accessory)
- Connecting power supply wiring
- Ground wire (Yellow/Green)
- Terminal block (X1M)
- Transmission wiring
- (To X1M (A1P) [TO IN/ D UNIT] (H1, H2))
- Terminal block (X1M (A1P))
- Insulation tube (Large) (accessory)

- Insulation tube (Small) (accessory)
- Cut off the insulation tube sticking out of the outdoor unit.

7-4 Transmission wiring connection procedure

- Between indoor units in the same system, pass the wiring between the units as shown in figure 25. (There is no polarity.)
- If an excessive force is applied while connecting a wire to the terminal block, the connection may be damaged.

(Refer to figure 25)

- Terminal block (X1M (A1P))
- Use balance type shield wire (with no polarity).
- Indoor unit
- Under no circumstances should 208/230V be connected.

Precautions regarding the length of wiring between units

Exceeding the following limits may cause transmission malfunctions, so observe them.

Farthest wiring length*1 (10 systems*2 or less)	Max. 3280 ft. (1000 m)
Farthest wiring length*1 (more than 10 systems*2)	Max. 2296 ft. (700 m)
Total wiring length	Max. 6560 ft. (2000 m)
Wiring length between units	Max. 656 ft. (200 m)
Max. no. of branches	20 (Up to 4 subbranches are available per system.)

*1 Wiring length from outdoor unit to farthest unit

*2 System: A set of units connected in the same refrigerant circuit

Precautions regarding wiring between units

- Do not connect 208/230V power supply wiring to terminals for the transmission wiring. Doing so would destroy the entire system.**
- Wiring to the indoor unit should be wired to H1 and H2 (TO IN/D unit) on the outdoor unit's terminal block (X1M (A1P)).

NOTE

- The above wiring should be wired using AWG18-16 (0.75-1.25 mm²) stranded, non-shielded wiring.
- All transmission wiring is to be procured on site.



CAUTION

Up to 4 subbranches per system are available.

Grandchild branch in wiring between units is not available.

(Refer to figure 26)

- Branch
- Subbranch
- Grandchild branch
- Caution on branches in the wiring among units

8. ADDITIONAL REFRIGERANT CHARGE

⚠ WARNING

- When leaving the unit with the power on, be sure to switch with another person doing the installation or close the front panel.




8-1 Before adding refrigerant

- Make sure the following work and inspection is complete, in accordance with the installation manual.
 - Piping
 - Wiring
 - Air tight test, Vacuum drying

8-2 Checking the refrigerant tank


- Check whether the tank has a siphon pipe before charging and place the tank so that the refrigerant is charged in liquid form. (See the figure below.)

Tank with siphon pipe



There is a siphon pipe inside, so the cylinder need not be upside-down to fill with liquid.
(Stand the cylinder upright when filling.)

Other tanks



Stand the tank upside down and charge.

8-3 Adding refrigerant

⚠ WARNING

- To avoid injury always use protective gloves and eye protection when charging refrigerant.
- To avoid injury do not charge with unsuitable substances. Use only the appropriate refrigerant.

⚠ NOTE

- Refrigerant cannot be charged until field wiring has been completed. Refrigerant may only be charged after performing the airtight test and the vacuum drying (Refer to **6-11 Air tight test and vacuum drying**).
When charging refrigerant into the system, take care that its maximum allowable charge is never exceeded, in view of the danger of liquid slugging.
Refrigerant containers shall be opened slowly.
To avoid compressor breakdown, do not charge the refrigerant more than the specified amount to raise the condensing pressure.

Filling after calculating the amount of refrigerant to add

- Calculate the amount of refrigerant to add as described in “**6. REFRIGERANT PIPING**”.
- After the vacuum drying is finished, open valve A (Refer to figure 27) and charge the calculated amount of refrigerant through the service port for the liquid-side stop valve.

Status of the stop valve and other valves when adding refrigerant

- See “Stop valve operation procedure” in “**6. REFRIGERANT PIPING**” for details on how to use the stop valve.
(Refer to figure 27)

- | | |
|-------------------------|----------------------------|
| 1. R32 Tank | 5. Stop valve service port |
| 2. Measuring instrument | 6. Gas line stop valve |
| 3. Valve A | 7. Outdoor unit |
| 4. Indoor unit | 8. Liquid line stop valve |

State of valve A and the stop valve	Valve A	Liquid line stop valve	Gas line stop valve
Before starting to charge the refrigerant	Close	Close	Close
During charging of the refrigerant	Open	Close	Close

- Close valve A after charging is complete.

Note: If all the refrigerant to be added cannot be charged using the above procedure, re-charge the refrigerant as below.

If all the refrigerant could not be added

Add refrigerant referring to the “Service Precautions” plate attached to the outdoor unit for details on the settings for adding refrigerant.

9. POST-WORK CHECKS

Perform the following checks after work is complete.

- Drain pipe connection, removal of transport bracket → See “**5. PRECAUTIONS ON INSTALLATION**”.
- Incorrect power supply wiring, loose screws → See “**7-3 How to connect the power supply wiring**”.
- Incorrect transmission wiring, loose screws → See “**7-4 Transmission wiring connection procedure**”.
- Incorrect refrigerant piping connections → See “**6. REFRIGERANT PIPING**”.
- Piping sizes, use of insulation → See : “**6-2 Selecting piping material**”.
“**6-6 Thermal insulation of piping**”.
- Stop valve check →
Make sure both the liquid-side and gas-side stop valves are open.
- Record of Amount of Refrigerant Added →
Record it on “Record of Amount of Refrigerant Added” on the “Service Precautions” label.
- Measuring the insulation of the main power circuit →
 - Use a 500V mega-tester.
 - Do not use the mega-tester for low voltage other than 208/230V. (Transmission wiring)

⚠ CAUTION

To the piping installer

After completing installation, be sure to open the valves.
(Operating the unit with the valve shut will break the compressor.)

10. TEST OPERATION

This unit is equipped with a crankcase heater to ensure smooth startup. Be sure to turn the power on at least 6 hours before operation in order to have power running to the crankcase heater.

⚠ WARNING

When leaving the unit with the power on, be sure to switch with another person doing the installation or close the front panel.






Precautions before turning the power on

- All indoor units connected to the outdoor unit operate automatically.
Complete work on the indoor units in order to ensure maximum safety.

10-1 Power On–Check Operation

- Make sure to perform the check operation after installation. (If the air conditioner is operated using the indoor remote controller without performing the check operation, the error code “U3” is displayed in the indoor remote controller, and normal operation is disabled.)
- When making settings on the outdoor unit PC board (A1P) after turning the power on, do not touch anything other than the push-button switches and dip switches. (See the “Service Precautions” plate for the locations of the pushbutton switches (BS1-3) and dip switches (DS1, 2) on the PC board (A1P).)
- When the unit configuration or transmission line connections has been changed (e.g., when using existing indoor or outdoor units, or an indoor unit or outdoor unit has been added, or indoor or outdoor unit PC board has been changed), be sure to perform the rewiring operation. The rewiring operation can be performed by pressing the BS3 pushbutton for at least 5 seconds. If not, the addition or change cannot be recognized. After the rewiring operation, the unit cannot be run until the address (indoor-outdoor address, etc.) is automatically set. If ON button on the remote controller is pushed during this time, the error code “U4” is displayed on the remote controller. (Returns to normal when automatic setting is complete.) (See the “Service Precautions” plate for the locations of the pushbutton switch BS3).
- During the operation, monitor the outdoor unit operation status and check for any incorrect wiring.

<p>1. Close the outdoor unit's front panel. Turn the power on for the outdoor unit and the indoor unit.</p>	<p>Caution Be sure to turn the power on at least 6 hours before operation in order to have power running to the crankcase heater.</p>
<p>2. Open the outdoor unit's front panel. When the communication between indoor units and outdoor unit (s) is established and normal, the segment indication state will be as follows (default situation when shipped from factory): When the power is turned on, the display lights up to confirm transmission.</p> <p style="text-align: center;"></p> <p>When no trouble occurs: lighted as indicated When there are zero connected indoor units: the display flashes on and off.</p> <p style="text-align: center;"></p> <p>Ready for operation: blank display indication as indicated.</p> <p style="text-align: center;"></p> <p>⚠ To avoid the risk of electric shock, do not touch anything other than the push-button switches on the PC board (A1P) when making settings. It may take up to several tens of minutes for the transmission confirmation to be completed. (Running a transmission line parallel to another system can cause signal congestion and take longer.)</p>	
<p>3. • When the customer requests quiet operation or demand operation, make these settings using the push-button switches (BS1-3) on the outdoor unit's PC board (A1P).</p> <p>• When connecting Cool/Heat selector, turn ON the DIP switch DS1-1 on the the outdoor unit's PC board (A1P). (Default: OFF) Refer to the manual of Cool/Heat selector.</p> <p>• Operate the push-button switches through the opening after protecting it with an insulation cover. (See the “Service Precautions” label for details.)</p>	<p>⚠ Use caution to avoid electric shock while working, since the outdoor unit is on.</p> <ul style="list-style-type: none"> • Only set the push-button switches (BS1-3) after making sure the operation pilot lamp on PC board is lit up. • See the “Service Precautions” label on the back side of the front panel for details on how to make the settings. (Do not forget to write the settings down on the “Service Precautions” label.) • The dip switch (DS1-2~4, DS2-1~4) does not need to be set, so do not touch it. Doing so may cause malfunction.

<p>4. • Check that the liquid and gas-side stop valves are open, and if they are closed, open them.</p>	<p>Caution Do not leave any stop valve closed otherwise the compressor will fail.</p>
<p>5. Press (BS2) at least five seconds and perform check operation. For details, see “How to perform check operation” on the “Service Precautions” label.</p> <ul style="list-style-type: none"> • The test operation is automatically carried out, the outdoor unit display will indicate t01 and the indication Test operation and Under centralized control will display on the user interface of indoor units. Steps during the automatic system test run procedure: <ul style="list-style-type: none"> - t01: control before start up (pressure equalization) - t02: cooling start up control - t03: cooling stable condition - t04: communication check - t05: stop valve check - t06: pipe length check - t07: - - t08: - - t09: pump down operation - t10: unit stop 	<ul style="list-style-type: none"> • During the test operation, the progress rate* will be displayed alternately with the display. • During the test operation, it is not possible to stop the unit operation from a user interface. To abort the operation, press BS3. The unit will stop after ±30 seconds. <p>* The progress rate is displayed in 00P-99P, but it may advance rapidly.</p> <ul style="list-style-type: none"> • If you have to leave the outdoor unit during check operation, either switch with another worker or close the front panel. • The system operates for about 30 minutes (60 minutes at maximum) and automatically stops the check operation. • The system can start normal operation about 5 minutes after the check operation if the remote controller does not display any error code. The remote controller will show the test operation display during check operation.
<p>6. Close the front panel of the outdoor unit after check operation is complete.</p>	

<Precautions During Check Operation>

- When above situation cannot be confirmed after 12 minutes, the error code can be checked on the indoor unit user interface and the outdoor unit segment display. Solve the error code accordingly. The communication wiring should be checked at first.
- In order to ensure uniform refrigerant distribution, it may take up to around 10 minutes for the compressor to start up after the unit begins running. This is not a malfunction.
- Each indoor unit cannot be checked individually for problems. After this operation is complete, run the unit normally using the remote controller.
- The check operation cannot be performed in other modes.
- If the discharge pipe thermistor (R21T), the suction pipe thermistor (R3T), and the pressure sensors (S1NPH and S1NPL) are removed before operation, the compressor might burn out, so avoid this under all circumstances.

10-2 Temperature control operation checklist

[Set the master unit (the indoor unit with rights of selection cooling or heating)]

<With a wired remote controller>

- After check operation is complete, displays of all the connected remote controllers will flash “Switching mode”.
- Ask the customer which indoor unit to set as the master unit. (Setting the most frequently used indoor unit as the master unit is recommended.)
- Press the mode-switch button on the remote controller for the master unit.
- That remote controller will then become the remote controller for switching between cooling and heating.
- All other remote controllers will display “Switching mode”.

<With wireless remote controller>

- After check operation is complete, the timer lamps on all the indoor units which are connected will flash.
- Ask the customer which indoor unit to set as the master unit. (Setting the most frequently used indoor unit as the parent unit is recommended.)
- Press the mode-switch button on the remote controller for the master unit. A beeping sound will be emitted and the timer lamps on all the indoor units will go off.
- That indoor unit will be the indoor unit which has the right to switch between cooling and heating. For details, see the operation manual which comes with the unit.
- After check operation is complete, check the temperature control using normal operation. (Heating is not possible if the outdoor temperature is 75°F (24°C) or higher.)
 - (1) Make sure the indoor and outdoor units are operating normally. (If liquid compression by the compressor or other abnormal noises can be heard, stop the unit immediately, heat the crankcase for a sufficient amount of time, and try again.)
 - (2) Run each indoor unit one at a time and make sure the corresponding outdoor unit is also running.
 - (3) Check to see if cold (or hot) air is coming out of the indoor unit.
 - (4) Press the fan direction and fan speed buttons on the indoor unit to see if they operate properly.

<Precautions during temperature control checks>

- For around 5 minutes after the compressor stops, the compressor will not run even if the “On/Off” button on the remote controller is pressed.
- When the system operation is stopped by the remote controller, the outdoor unit may continue operating for up to 1 minute.
- Error code “U3” is displayed if check operation is not performed using the test run button the first time after installation. Perform the check operation in accordance with “10-1 Power On– Check Operation”.

[Remote controller displays error code]
(Check on a remote controller.)

Error code	Installation error	Remedial action
E3	The stop valve of an outdoor unit is left closed.	Open the gas-side stop valve and the liquid-side stop valve.
	Refrigerant overcharge.	Recalculate the required amount of refrigerant from the piping length and correct the refrigerant charge level by recovering any excessive refrigerant with a refrigerant recovery unit.
E4	The stop valve of an outdoor unit is left closed.	Open the gas-side stop valve and the liquid-side stop valve.
	Insufficient refrigerant.	Check if the additional refrigerant charge has been finished correctly. Recalculate the required amount of refrigerant from the piping length and add an adequate amount of refrigerant.

F3	The stop valve of an outdoor unit is left closed.	Open the gas-side stop valve and the liquid-side stop valve.
	Insufficient refrigerant.	Check if the additional refrigerant charge has been finished correctly. Recalculate the required amount of refrigerant from the piping length and add an adequate amount of refrigerant.
U2	Insufficient power supply voltage	Check to see if the power supply voltage is supplied properly.
U3	If a check operation has not been performed.	Perform a check operation.
U4	No power is supplied to an outdoor unit.	Turn the power on for the outdoor unit.
UA	If no dedicated indoor unit is being used.	Check the indoor unit. If it is not a dedicated unit, replace the indoor unit.
UF	The stop valve of an outdoor unit is left closed.	Open the gas-side stop valve and the liquid-side stop valve.
	If the right indoor unit piping and wiring are not properly connected to the outdoor unit.	Make sure that the right indoor unit piping and wiring are properly connected to the outdoor unit.

- When using a central controller, see the installation manual or service manual which came with the central controller.

[If nothing is displayed on the remote controller]

- There might be a problem with the connections or communication between the indoor unit and the remote controller. Make sure all the wiring is properly connected.

—  **CAUTION** —

To the piping installer, To the electrician

After the test operation, when handing the unit over to the customer, make sure the front panel on the unit and all screws are attached.

11. ENERGY SAVING AND OPTIMUM OPERATION

This VRV heat pump system is equipped with two kinds of advanced energy saving functionality (VRT and VRT smart control). After detecting all connected indoor unit type, advanced energy saving functionality type is selected automatically. Depending on the priority, emphasis can be put on energy saving or comfort level. Several parameters can be selected, resulting in the optimal balance between energy consumption and comfort for the particular application.

Several patterns are available and explained on the next page. Modify the parameters to the needs of your building and to realize the best balance between energy consumption and comfort.

Refer to Service Manual for changing the field settings.

Setting definition:[A-B]=C;A=mode,B=setting NO.,C=setting value.

<Precautions regarding VRT smart control operation>

- When the operation mode is changed over from Cool to Dry during VRT smart control, it will be back to Cool after a certain period of time to prevent the system from repeating ON/OFF for energy saving. Refer to Service Manual for the period of Dry operation which can be changed by field setting.

11-1 Four main operation methods are available:

• Basic

The refrigerant temperature is fixed independent from the situation. It corresponds to the standard operation which is known and can be expected from/under previous VRV systems:

- To activate this operation method under cooling operation: Change field setting [2-64]=1 or disconnect the circuit between terminal on external control adapter with [2-7]≠0.
- To activate this operation method under heating operation: Change field setting [2-64]=2 or disconnect the circuit between terminal on external control adapter with [2-7]≠0.

• **Automatic for VRT control**

The refrigerant temperature is set depending on the outdoor ambient conditions. As such adjusting the refrigerant temperature to match the required load (which is also related to the outdoor ambient conditions). E.g., when your system is operating in cooling, you do not need as much cooling under low outdoor ambient temperatures (e.g., 77°F (25°C)) as under high outdoor ambient temperatures (e.g., 95°F (35°C)). Using this idea, the system automatically starts increasing its refrigerant temperature, automatically reducing the delivered capacity and increasing the system's efficiency.

- This operation is selected automatically with checking connected indoor unit type.

E.g., when your system is operating in heating, you do not need as much heating under high outdoor ambient temperatures (e.g., 68°F (20°C)) as under low outdoor ambient temperatures (e.g., 23°F (-5°C)). Using this idea, the system automatically starts decreasing its refrigerant temperature, automatically reducing the delivered capacity and increasing the system's efficiency.

- This operation is selected automatically with checking connected indoor unit type.

• **Automatic for VRT smart control**

The refrigerant temperature is set depending on the required capacity sent from every indoor unit.

- This operation is selected automatically with checking connected indoor unit type.

• **Hi-sensible**

The refrigerant temperature is set higher/lower (cooling/heating) compared to basic operation.

The focus under high sensible mode is comfort feeling for the customer.

The selection method of indoor units is important and has to be considered as the available capacity is not the same as under basic operation. For details concerning to Hi-sensible applications, please contact your dealer.

- To activate this setting under cooling operation: change field setting [2-8] to the appropriate value, matching the requirements of the pre-designed system containing a high sensible solution.

Value [2-8]	Te target
0	Auto
2	43°F (6°C) (default)
3	45°F (7°C)
4	46°F (8°C)
5	48°F (9°C)
6	50°F (10°C)
7	52°F (11°C)

- To activate this setting under heating operation: change field setting [2-9] to the appropriate value, matching the requirements of the pre-designed system containing a high sensible solution.

Value [2-9]	Tc target
0	Auto
1	106°F (41°C)
3	109°F (43°C)
6	115°F (46°C) (default)

11-2 Several comfort settings are available in VRT control/ VRT smart control

A comfort level can be set for VRT control/ VRT smart control mode and hi-sensible mode. The comfort level is related to the time and power (energy consumption) expended in order to achieve a certain room temperature.

The requested conditions are achieved more quickly by temporarily changing the refrigerant temperature.

• **Powerful**

Overshoot (during heating operation) or undershoot (during cooling operation) is allowed compared to the requested refrigerant temperature, in order to achieve the required room temperature very fast. The overshoot or undershoot is allowed from the start up moment. In case of cooling operation the evaporating temperature is allowed to go down to 37°F (3°C) on temporary base depending on the situation. In case of heating operation the condense temperature is allowed to go up to 120°F (49°C) on temporary base depending on the situation. When the request from the indoor units becomes more moderate, the system will eventually go to the steady state condition which is defined by the operation method above.

- To activate the powerful comfort setting under cooling operation, change field setting [2-81]=3.
- To activate the powerful comfort setting under heating operation, change field setting [2-82]=3.

• **Quick**

Overshoot (during heating operation) or undershoot (during cooling operation) is allowed compared to the requested refrigerant temperature, in order to achieve the required room temperature very fast. The overshoot or undershoot is allowed from the start up moment. In case of cooling operation the evaporating temperature is allowed to go down to 43°F (6°C) on temporary base depending on the situation. In case of heating operation the condense temperature is allowed to go up to 115°F (46°C) on temporary base depending on the situation. When the request from the indoor units becomes more moderate, the system will eventually go to the steady state condition which is defined by the operation method above.

- To achieve the quick comfort setting under cooling operation, change field setting [2-81]=2.
- To achieve the quick comfort setting under heating operation, change field setting [2-82]=2.

• **Mild (default)**

Overshoot (during heating operation) or undershoot (during cooling operation) is allowed compared to the requested refrigerant temperature, in order to achieve the required room temperature very fast. The overshoot or undershoot is not allowed from the start up moment. The start up occurs under the condition which is defined by the operation mode above.

In case of cooling operation the evaporating temperature is allowed to go down to 43°F (6°C) on temporary base depending on the situation. In case of heating operation the condense temperature is allowed to go up to 115°F (46°C) on temporary base depending on the situation. When the request from the indoor units becomes more moderate, the system will eventually go to the steady state condition which is defined by the operation method above.

The start up condition is different from the powerful and quick comfort setting.

- To activate the mild comfort setting under cooling operation, change field setting [2-81]=1.
- To activate the mild comfort setting under heating operation, change field setting [2-82]=1.


• **Eco**

The original refrigerant temperature target, which is defined by the operation method (see above) is kept without any correction, unless for protection control.

- To activate the eco comfort setting under cooling operation, change field setting [2-81]=0.
- To activate the eco comfort setting under heating operation, change field setting [2-82]=0.


No matter which control is selected, variations on the behaviour of the system are still possible due to protection controls to keep the unit operating under reliable conditions. The intentional target, however, is fixed and will be used to obtain the best balance between energy consumption and comfort, depending on the application type.

Example: Automatic mode during cooling




- A** Actual load curve
- B** Virtual load curve (initial capacity automatic mode)
- C** Virtual target value (initial evaporation temperature value automatic mode)
- D** Required evaporation temperature value
- E** Load factor
- F** Outside air temperature
- T_e** Evaporating temperature
- Quick
- Powerful
- Mild

Example: Automatic mode during cooling




- A** Virtual load curve (default automatic mode peak capacity)
- B** Load curve
- C** Virtual target value (initial condensation temperature value automatic mode)
- D** Design temperature
- E** Load factor
- F** Outside air temperature
- T_c** Condensing temperature
- Quick
- Powerful
- Mild

Room temperature evolution:



- A** Indoor unit set temperature
- B** Operation start
- C** Operating time
- D** Mild
- E** Quick
- F** Powerful

Room temperature evolution:



- A** Indoor unit set temperature
- B** Operation start
- C** Operating time
- D** Mild
- E** Quick
- F** Powerful

12. CAUTION FOR REFRIGERANT LEAKS

(Points to note in connection with refrigerant leaks)

Introduction


These systems are charged with R32 refrigerant. Please refer to ASHRAE 15 and local standards and building code as applicable when installing this equipment. In the absence of codes, the following guidelines could be considered.

Maximum concentration level

The maximum charge of refrigerant and the calculation of the maximum concentration of refrigerant can be determined based on the humanly occupied space into which it could leak.

The unit of measurement of the concentration is lbs/ft³ (the weight in lbs of the refrigerant gas in 1ft³ volume of the occupied space).

Compliance to the local applicable regulations and standards for the maximum allowable concentration level is required.



Pay a special attention to places, such as basements, etc. where refrigerant can stay, since refrigerant is heavier than air.

Procedure for checking maximum concentration

Check the maximum concentration level in accordance with steps 1 to 4 below and take whatever action is necessary to comply.


1. Calculate the amount of refrigerant (lbs) charged to each system separately.

amount of refrigerant in a single unit system (amount of refrigerant with which the system is charged before leaving the factory)	+	additional charging amount (amount of refrigerant added locally in accordance with the length or diameter of the refrigerant piping and type of indoor units)	=	total amount of refrigerant (lbs) in the system
-----------------------------------------------------------------------------------------------------------------------------------	---	---------------------------------------------------------------------------------------------------------------------------------------------------------------	---	-------------------------------------------------


NOTE

- Where a single refrigerant facility is divided into 2 entirely independent refrigerant systems then use the amount of refrigerant with which each separate system is charged.
2. Calculate the smallest room volume (ft³)
For instance, in the following, calculate the volume of (A), (B) as a single room or as the smallest room.

A. Where there are no smaller room divisions



B. Where there is a room division but there is an opening between the rooms sufficiently large to permit a free flow of air back and forth. Refer to code requirements for opening size and location requirements.



(Where there is an opening without a door or where there are openings above and below the door which are each equivalent in size to 0.15% or more of the floor area.)

3. Calculating the refrigerant concentration by using the results of the calculations in steps 1 and 2 above.


$$\frac{\text{total volume of refrigerant in the refrigerant system}}{\text{size (ft}^3\text{) of smallest room in which there is an indoor unit installed}} \leq \text{maximum concentration level (lbs/ft}^3\text{)}$$

If the result of the above calculation exceeds the maximum concentration level then make similar calculations for the second then third smallest room and so until the result falls short of the maximum concentration.

4. Ensure that the calculated possible concentration level does not exceed the maximum concentration level in the case of each room. Where the installation of a facility results in a concentration in excess of the maximum concentration level then it will be necessary to revise the system and/or design. Please consult your dealer.

13. WIRING DIAGRAM

WIRING DIAGRAM



LAYOUT OF EL. COMPO. ASSY

LAYOUT OF MIF, M1C, EL. COMPO. ASSY

NOTES

- THIS WIRING DIAGRAM APPLIES ONLY TO THE OUTDOOR UNIT.
- FIELD WIRING: PROTECTIVE GROUND (SCREW): TERMINAL BLOCK: NOISELESS GROUND: TERMINAL: CONNECTION: CONNECTOR
- WHEN USING THE OPTIONAL ACCESSORIES, REFER TO THE INSTALLATION MANUAL OF THE OPTIONAL ACCESSORIES.
- FOR CONNECTION WIRING FROM OUTDOOR-INDOOR TRANSMISSION H1 · H2, OUTDOOR-OUTDOOR TRANSMISSION H1 · H2 REFER TO INSTALLATION MANUAL.
- HOW TO USE BS1~BS3 SWITCH, REFER TO "SERVICE PRECAUTIONS" LABEL ON BACK SIDE OF FRONT PLATE.
- WHEN OPERATING, DO NOT SHORT-CIRCUIT PROTECTION DEVICES (S1PH AND Q1E).
- COLOR: BLK: BLACK: RED: RED: BLU: BLUE: WHT: WHITE: GRN: GREEN.
- CLASS 2 WIRE.
- THE POSITIONS OF THE SELECTOR SWITCHES (DS1, DS2) INDICATE FACTORY SETTING. REFER TO THE SERVICE MANUAL IN DETAIL.

A1P	PRINTED CIRCUIT BOARD (MAIN)	R10T	THERMISTOR (FIN)
A2P	PRINTED CIRCUIT BOARD (ACS)	R11T	PTC THERMISTOR
A3P	PRINTED CIRCUIT BOARD (COMP. INV.)	R21T	THERMISTOR (DISCHARGE PIPE)
C1	CAPACITOR	R2V	VARIATOR
BS1~BS3	PUSH BUTTON SWITCH (A1P) (MODE, SET, RETURN)	SEG1~SEG3	7-SEGMENT DISPLAY (A1P)
DS1, DS2	DIP SWITCH	STNPH	PRESSURE SENSOR (HIGH)
E1HC	CRANKCASE HEATER	STNPL	PRESSURE SENSOR (LOW)
FOU~F5U	FUSE	S1PH	PRESSURE SWITCH (HIGH)
H1P	PLOT LAMP (SERVICE MONITOR-RED)	V1R	DIODE BRIDGE
HAP	FLASHING LAMP (SERVICE MONITOR-GREEN)	V2R, V3R	IGBT POWER MODULE
K1R~K4R	MAGNETIC RELAY	X1M	TERMINAL BLOCK (POWER SUPPLY)
K11M	MAGNETIC CONTACTOR	X1M	TERMINAL BLOCK (CONTROL) (A1P)
M1C	MOTOR (COMPRESSOR)	Y1E	ELECTRONIC EXPANSION VALVE (MAIN)
M1F	MOTOR (FAN)	Y2E	ELECTRONIC EXPANSION VALVE (INVERTER COOLING)
PFC	POWER FACTOR CORRECTION	Y3E	ELECTRONIC EXPANSION VALVE (SUBCOOL HEAT EXC.)
PS	SWITCHING POWER SUPPLY	Y4E	ELECTRONIC EXPANSION VALVE (INJECTION)
Q1E	OVERLOAD PROTECTOR	Y1S	SOLENOID VALVE (4 WAY VALVE)
R1, R2	RESISTOR (CURRENT SENSOR)	Z1C~Z5C	FERRITE CORE
R1T	THERMISTOR (AIR)	Z1F	NOISE FILTER
R3T	THERMISTOR (SUCTION PIPE)		
R4T	THERMISTOR (HEAT EXC. LIQUID PIPE)		CONNECTOR FOR OPTIONAL ACCESSORIES
R5T	THERMISTOR (SUBCOOLED LIQUID PIPE)	X12A	CONNECTOR (DRAIN PAN HEATER)
R6T	THERMISTOR (SUBCOOLED GAS PIPE)	X37A	CONNECTOR (OPTION ADAPTOR)
R7T	THERMISTOR (DEICER)	X66A	CONNECTOR (C/H SELECTOR)

3D151135-1C

DAIKIN COMFORT TECHNOLOGIES MANUFACTURING, L.P.

Daikin Texas Technology Park,
19001 Kermier Road,
Waller, TX, 77484, U.S.A.

