

Daikin One+ and Touch Thermostat Commissioning Menu Outline for Unitary Equipment, v3.9 software

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Default	Display only?	Conditions	
welcome	english español française	(radio buttons)				english			
	use large font	(checkbox)				unchecked			
	continue								
equipment type	unitary (radio button)	cancel continue				unitary			
	single/multi-split (S21) (radio button)								
	VRV, SkyAir, single/multi-split (P1P2) (radio button)								
	continue								
setup	begin setup	(to smart thermostat setup with 5 main steps below)							
	setup options	factory reset							
	learn more	firmware (version #) check for update					Yes		
	thermostat ID (DKN number)	(2D barcode of DKN number for cloud commissioning) dismiss					Yes		
							Yes		
1. Communication	equipment type	unitary				unitary			
		mini/multi-split (S21)							
		VRV, SkyAir, mini/multi-split (P1P2)							
	wifi	use wifi							
		networks	(list of available networks) search again				Only appears when "use wifi" selected		
		internet connected (tickmark)					Only appears when connected to active wifi network		
		Daikin One Cloud connected (tickmark)					Only appears if successfully connect to internet.		
		legal notices	terms of use (text) privacy policy (text) end user license agreement (text)				Yes Yes Yes		
		restart thermostat					Yes	If internet connected but not cloud	
2. Personalization	language	english español française				english			
	use large font	(checkbox)				unchecked			
	date & time	(month, day, and year selection)						set automatically when connect to WiFi.	
		(hour, minute, and am/pm selection)						set automatically when connect to WiFi.	
		use 24-hour time format				disabled			
		time zone	(list of time zones)			Pacific		set automatically when connect to mobile app.	
	name	main room upstairs downstairs hallway bedroom kitchen other (other name)	(text entry for other)			main room			
	degree units	fahrenheit celsius				fahrenheit			
3. Product Configuration	Air Conditioner (model # from CT)	Specifications	Model #				Yes	If scan successful	
			Serial #				Yes		
			Control Software Version				Yes		
			Inverter Software Version				Yes	Inverter only	
			Number of cool stages				Yes		
			Number of heat stages				Yes	Will display for AC, as "0" stages.	
			Tonnage				Yes		
		Cool Settings	Low speed trim	-15% to 15% in 3% steps					
				-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max					
								Inverter AC only, but not with DTA furnace adaptors	
	Heat Pump (model # from CT)		Cool Airflow Trim	Intermediate speed trim	-15% to 15% in 3% steps				
					-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max				
								Inverter AC only, but not with DTA furnace adaptors	
				High speed trim	-15% to 15% in 3% steps				
					-15%, -10, -5, 0, 5, 10, 15				
								Fit AC from Mar. 2020, but not with DTA furnace adaptors	
			Cool Profile	Profile A Profile B Profile C Profile D					
								Not available with DTA furnace adaptors	
				Cool Airflow ON Delay Cool Airflow OFF Delay Max compressor RPS	0, 5, 10, 20, 30s 0, 30, 60, 90, 120s 0s			0s option added to Fit in 2025. 0s option added to Fit in 2025.	
			RPS offset	RPS offset	0 to 20 in 0.5 RPS steps				
								0s option added to Fit in 2025.	
				Off, On					
			Dehumidification	Off, Standard, A (widest range), B (reduced range), C (100% operation only)					
				Circulation selection	Off, On			Fit AC from Mar. 2020	
	Heat Pump (model # from CT)	Specifications	Model #				Yes		
			Serial #				Yes		
			Control Software Version				Yes		
			Inverter Software Version				Yes	Inverter only	
			Number of cool stages				Yes		
			Number of heat stages				Yes		
			Tonnage				Yes		
		Cool Settings	Low speed trim	-15% to 15% in 3% steps					
				-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max					
								Fit HP from Mar. 2020, but not with DTA furnace adaptors	
		Heat Pump Settings	Cool Airflow Trim	Intermediate speed trim	-15% to 15% in 3% steps				
					-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max				
								Inverter HP only, but not with DTA furnace adaptors	
				High speed trim	-15% to 15% in 3% steps				
					-15%, -10, -5, 0, 5, 10, 15				
								Fit HP from Mar. 2020, but not with DTA furnace adaptors	
			Cool Profiles	Profile A Profile B Profile C Profile D					
								Not available with DTA furnace adaptors	
				Cool Airflow ON Delay	0, 5, 10, 20, 30s			0s option added to Fit in 2025.	

Heat Pump (model # from CT)	Heat Settings	Cool Airflow OFF Delay	0, 30, 60, 90, 120s			0s option added to Fit in 2025.
		Max compressor RPS			Yes	Inverter only
		Max RPS offset	0 to 20 in 0.5 RPS steps			Inverter only; can't be changed for All-climate HP and 5-ton enhanced FIT
		Dehumidification	Off, Standard, A (widest range), B (reduced range), C (100% operation only)			Fit HP from Mar. 2020
		Circulation selection	Off, On			Fit HP from May 2021
	Heat Pump Settings	Heat Airflow Trim	Low speed trim	~-15% to 15% in 3% steps		Inverter HP only, but not with DTA furnace adaptors
				~-15%, -10, -5, 0, 5, 10, 15		Fit HP from Mar. 2020, but not with DTA furnace adaptors
			Intermediate speed trim	~-15% to 15% in 3% steps		Inverter HP only, but not with DTA furnace adaptors
				~-15%, -10, -5, 0, 5, 10, 15		Fit HP from Mar. 2020, but not with DTA furnace adaptors
			High speed trim	~-15% to 15% in 3% steps		Inverter HP only, but not with DTA furnace adaptors
				~-15%, -10, -5, 0, 5, 10, 15		Fit HP from Mar. 2020, but not with DTA furnace adaptors
		Heat Airflow ON Delay	0, 5, 10, 15s			2-stage models only
		Heat Airflow OFF Delay	0, 30, 50, 70, 90s			0s option added to Fit in 2025.
		Backup Defrost Heat	always on; always off; below temperature: 30°F, 35°F, 40°F, 45°F, 50°F, 55°F, 60°F, 65°F;			Fit Heat Pump only
		Defrost Interval	30, 60, 90, 120 min; 2 hr, 6 hr, 12 hr, 24hr.			R410A HP only
Furnace (model # from CT)	Heat Settings	Defrost Compressor Delay	0, 5, 15, 30s			R32 HP only, from mid-2025
		Max compressor RPS			Yes	2-stage R410A HP only
		Max RPS offset	0 to 20 in 0.5 RPS steps			Inverter only; can't be changed for All-climate HP and 5-ton enhanced FIT
		heat pump lockout temp	-40°F to 65°F in 5°F steps (-40°C to 17.5°C in 2.5°C steps)		-5°F (-20°C)	Only displayed for systems with HP and heater kit. Is common lockout with aux heat source.
		supplemental heat lockout	-10°F to 75°F in 5°F steps (-22.5°C to 22.5°C in 2.5°C steps)		50°F (10°C)	Only displayed for systems with HP and heater kit. Doesn't apply to an aux heat source.
	Humidifier Relay	balance point	-10°F to 75°F in 5°F steps (-22.5°C to 22.5°C in 2.5°C steps)		50°F (10°C)	Only displayed for dual-fuel systems (HP and gas furnace).
		prioritize efficiency (on) prioritize comfort	(radio buttons)		prioritize comfort	Only displayed for dual-fuel systems (HP and gas furnace).
		Model #			Yes	
		Serial #			Yes	
		Control Software Version			Yes	
3. Equipment Setup	Air Handler or Blower (model # from CT)	number of heat stages			Yes	
		Size/Capacity			Yes	Not DTA furnace adaptors
		Blower Motor Size			Yes	Not DTA furnace adaptors
		Gas Heat Airflow Trim	-10% to 16% in 2% steps ~-15% to 15% in 3% steps		-10% to 10% in 2% steps	R32 compatible furnaces Modulating R410A furnaces only
		Gas Heat Airflow ON Delay	5 to 30s in 5s steps			2-stage R410A furnaces only, not DTA furnace adaptors
	Humidifier Relay	Gas Heat Airflow OFF Delay	30 to 180s in 30s steps			Modulating and 2-stage R410A furnaces, not DTA furnace adaptors
		Heat CFM Taps	Tap A Tap B Tap C Tap D			Mod and 2-stage R410A furnaces. At launch of R32 furnaces, must be modified on PCB or using CoolCloud app. (not supported on DTA furnace adaptors or mod or R410A ULN furnaces)
		Mode	Off On with heat and hum On with hum		Off	Daikin 2-stage and mod R410A furnaces and all R32 furnaces (not DTA furnace adaptors, or R410A ULN) "On with hum" option not supported in R32 furnaces.
		Humidification Fan Speed	25, 50, 75, 100%			2-stage R410A furnaces only, and only when "on with hum" (aka "independent") selected.
		Aux Alarm	On/Off			2-stage and ULN R410A furnaces, and all R32 furnaces
Coil	Heater Kit	Model #			Yes	
		Serial #			Yes	
		Control Software Version			Yes	
		Blower Motor Size			Yes	
		Is a heater kit installed?	Yes/No		No	Non-EEV air handlers that support heater kits (used to confirm installed heater kit)
		Size (kW)	(size in kW from indoor PCB)		Yes	non-EEV air handlers
			0, 3, 5, 6, 8, 10kW			DV28FEC, DV24FEC, DV24E24, and DVME24 models that support heater kits
			0, 5, 6, 8, 10, 15, 19kW			DV35FEC, DV36FEC, DV37PEC, DV42FEC, DVFE35, DVFE36, DVFE42, and DVME36 models that support heater kits
			0, 5, 6, 8, 10, 15, 20kW			DV47FEC, DV48FEC, DV59PEC, DVFE47, DVFE48, and DMVE48 models that support heater kits
			0, 5, 6, 8, 10, 15, 20, 25kW			DV61PEC, DV59FEC, DV60FEC, DVFE59, DVFE60, and DMVE60 models that support heater kits
	Hum/aux Relay	0, 3, 5, 15kW				MBVK1CH1X
		0, 5, 15, 20, 25kW				MBVK2CH1X
		0, 3kW				AWVE30, AWVE36
		0% to 10% in 2% steps				EEV air handlers only, including MBVKxxCH models
		Electric Heat Airflow Trim	-10% to 10% in 2% steps			non-EEV air handlers (ClimateTalk models with TXV) including MBVKxxP (TXV) models
	Aux Alarm	Heat Airflow ON Delay			Yes	
		Heat Airflow OFF Delay			Yes	
		Humidifier Enable with Blower None				EEV air handlers only
		Humidification Mode	Off On Independent			EEV air handlers only, if humidifier selected in top menu
		Humidification Fan Speed	25, 50, 75, 100%			EEV air handlers only, if "humidifier" and "Independent" selected above.
		Aux Alarm	On/Off			non-EEV air handlers and blowers.
	Configuration	Serial #			Yes	
		Software Version			Yes	
		1, 2			1	

Media filter	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
Add Equipment	air quality sensor					Mod or 2-stage R410A furnace only. At launch of R32 furnaces, settings must be modified on PCB or using CoolCloud app. (not supported on R410A ULN furnaces). Only appears if no communicating AC or HP detected.
	24V AC Condenser					
	Humidifier					Can only add 1 of each type.
	Dehumidifier					Can only add 1 of each type.
	Aux heat source					Can only add 1 of each type.
	UV bulb					Can only add 1 of each type.
	HEPA filter					Can only add 1 of each type.
	Electronic filter	low speed trim				Can only add 1 of each type.
	Remote Sensor	pair sensor (goes to "edit sensor" screen)				One+ thermostats only, can add up to 8.
	EWC Zone board	cancel				Can only add 1 of each type.
Indoor air quality sensor	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
24V AC Condenser	Cool Settings	Cool CFM	18, 24, 30, 36, 42, 48, 60 kBtUs cooling			For R32 furnaces, must use CoolCloud app.
		Cool Airflow Trim	-15% to 15% in 3% steps			R410A modulating furnace only. For R32 furnaces, must use CoolCloud app.
			-10% to 10% in 2% steps			R410A 2-stage furnace only. For R32 furnaces, must use CoolCloud app.
		Cool Profiles	Profile A			For R32 furnaces, must use CoolCloud app.
			Profile B			
			Profile C			
			Profile D			
		Cool Airflow ON Delay	5, 10, 20, 30s			R410A modulating furnace only. For R32 furnaces, must use CoolCloud app.
			1, 5, 10, 20, 30s			R410A 2-stage furnace only. For R32 furnaces, must use CoolCloud app.
			30, 60, 90, 120s			R410A modulating furnace only. For R32 furnaces, must use CoolCloud app.
		Cool Airflow OFF Delay	0, 30, 60, 90, 120s			R410A 2-stage furnace only. For R32 furnaces, must use CoolCloud app.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			For R32 furnaces, can only add or remove from thermostat.
Humidifier	Connection	Aux1				If humidifier added.
		Aux2				
	Control	On with heat On with heat and hum On with hum			On with heat and hum call	
	Fan speed	25% 50% 75% 100%				
	number of pads	1, 2				
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
Dehumidifier	Connection	Aux1				If dehumidifier added.
		Aux2				
	Control	On with cool On with cool and dehum On with dehum On with no cool and dehum			On with dehum	
	Fan speed	0% 25% 50% 75% 100%			100%	
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
Aux heat source	Connection	Aux1				
		Aux2				
		Aux heat lockout	-40°F to 65°F in 5°F steps (-40°C to 17.5°C in 2.5°C steps)	-5°F (-20°C)		The whole "Heat Pump is primary heat source" only appears if connected to HP. The HP lockout must be at least 10°F < aux heat lockout.
			Enable aux heat lockout (checkbox)	disabled		
			-10°F to 75°F in 5°F steps (-22.5°C to 22.5°C in 2.5°C steps)	50°F (10°C)		Appears if connected to HP.
			Use Ton/Toff (checkbox)	disabled		If connected to HP
			Turn on temperature differential: -7°F to -3°F in 1°F steps (-4.0°C to -1.5 to in 0.5°C steps)	-3°F (-1.5°C)		Enabled automatically if connected to AC outdoor.
			Turn off temperature differential: -4°F to 1°F in 1°F steps (-2°C to 0.5°C in 0.5°C steps)	1°F (0.5°C)		Enabled automatically if connected to AC outdoor. Must be 3 or 4°F (2°C) above Ton.
			Indoor unit fan enabled (checkbox)	On		
			Fan speed	low medium high		Only if indoor unit fan enabled.
			Fan on delay	0s, 30s, 60s, 120s, 180s, 240s, 300s	30s	Only if indoor unit fan enabled.
			Fan off delay	0s, 10s, 30s, 60s, 90s, 120s, 180s	10s	Only if indoor unit fan enabled.
		T on / T off	-40°F to 65°F in 5°F steps (-40°C to 17.5°C in 2.5°C steps)	15°F (-10°C)		
			Setpoint differential (-5°C to -1°C in 1°C steps)	-2°F (-1°C)		Hidden for AC outdoor unit
			Turn on temperature differential: -2 or -1°F (-1.0 or -0.5°C)	-1°F (-0.5°C)		
			Turn off temperature differential: 1°F (0.5°C)	1°F (0.5°C)	Yes	
			Indoor unit fan enable (checkbox)	On		
			Fan speed	low medium high		Only if indoor unit fan enabled.
		Fan on delay	0s, 30s, 60s, 120s, 180s, 240s, 300s	30s		Only if indoor unit fan enabled.
			Fan off delay	0s, 10s, 30s, 60s, 90s, 120s, 180s	10s	Only if indoor unit fan enabled.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
UV Bulb	1, 2				1	If UV bulbs added.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
HEPA filter	1, 2				1	If HEPA filter added.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			
Electronic filter	1, 2				1	If Electronic filter added.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue			

4. System Optimization	Remote Sensors	include thermostat (temp/hum values)	checkbox				One+ thermostats only
		edit sensor				Yes	
		sensor name	(text entry)			Yes	
		sensor type	surface mount			Yes	
		temperature calibration	-7°F to 7°F in 1°F steps (or) -3.5°C to 3.5°C in 0.5°C steps			Yes	
		humidity calibration	-15% to 15% in 1% steps			Yes	
		save				Yes	
		cancel				Yes	
	sensor1 (temp/hum values) (up to 8 sensors)	remove	Are you sure you want to remove this sensor?	remove	cancel		
	sensor2 (temp/hum values) (same as above)						
	Type	EWC Zone Board				Yes	If zone board added
	Zone 1	(radio button)			Zone 1		
	Additional Zone						
	EWC Zone Board	heater kit installed	(checkbox)		No		Appears when "Additional Zone" selected to tell thermostat to heater kit.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
	System Test	Run test (explanation of test)					Only in inverter AC and HP
		Test status:	0: "System test required" 1: "Initial test successful"				
	Charge Mode	Run test Stop (explanation of test)					Only R410A Inverter AC/HP.
	Charge Verification Mode	Run test Stop (explanation of test)	1: "Outdoor Temp out of range - Please use gauges to adjust charge" 2: "System stabilizing" 3: "Outdoor fan speed not in range" 4: "Compressor speed not in range" 5: "Indoor SH not in range" 6: "In range - SubCool = (SC in °F or °C)" 7: "SC in range - confirming continuous"				Only R32 Inverter AC/HP.
	Refrigerant Leak Test	Refrigerant leak test	Run test Stop (explanation of test)				R32 EEV air handlers only.
	Optional Tests	Cooling	Run test Stop (explanation of test)				If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Fan	Run test Stop (explanation of test)				Runs until stopped or until setup steps completed.
		Heat Pump Heat	Run test Stop (explanation of test)				If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Gas Heat	Run test Stop (explanation of test)				If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Electric Heat	Run test Stop (explanation of test)				If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Pump Down	Run test Stop (explanation of test)				All-climate HP, Enhanced 5-ton, and some older inverter models.
		Error History	(date and time of error) (code - equipment) (error description)			Yes	
		Clear error history?	Cancel/Continue	Yes/No			
	Calibration	Temperature calibration	-10°F to 10°F in 1°F steps (or) -5.5°C to 5.5°C in 0.5°C steps		0°F (or) 0°C		
		Humidity calibration	-15% to 15% in 1% steps		0%		
	Status	air conditioner (or) heat pump	operation mode			Yes	all equipment, enhanced for Fit AC/HP from May 2021.
			current critical error			Yes	if currently active critical error
			current minor error			Yes	if currently active minor error
			requested heat demand			Yes	Only HP models.
			requested cool demand			Yes	all equipment
			requested indoor CFM			Yes	all equipment
			requested indoor fan demand			Yes	inverter always shows "0%", may only display for 2-stage where is valid.
			requested dehum demand			Yes	all equipment
			indoor superheat			Yes	R32 models only
			refrigerant type			Yes	R32 models only
			compressor runtime			Yes	inverter only
			compressor reduction mode			Yes	inverter only
			outdoor fan RPM			Yes	inverter only, except DZ18TC models
			outdoor fan tap			Yes	DZ18VC models only
			outdoor air temp			Yes	all equipment
			outdoor coil temp			Yes	Not 2-stage, All-climate HP, or 5-ton Enhanced FIT
			liquid temperatures			Yes	inverter only
			discharge temperature			Yes	inverter only
			outdoor defrost sensor temp			Yes	inverter HP only
			suction temperature			Yes	inverter only
			suction pressure			Yes	inverter only
			high pressure sensor			Yes	All-climate HP and 5-ton enhanced models only
			retry code			Yes	Fit or 20 SEER (late '22)
			inverter current (A)			Yes	Fit or 20 SEER (late '22)
			inverter fin temp			Yes	Fit or 20 SEER (late '22)
			current compressor speed (%)			Yes	Fit or 20 SEER (late '22)
			current compressor speed (RPS)			Yes	Fit or 20 SEER (late '22)
			target compressor speed (RPS)			Yes	Fit or 20 SEER (late '22)
			request for compressor			Yes	Fit or 20 SEER (late '22)
			reversing valve			Yes	Fit or 20 SEER (late '22)
			request for OD fan			Yes	Fit or 20 SEER (late '22)
			OD fan motor current (A)			Yes	Fit or 20 SEER (late '22)
			target OD fan speed (RPM)			Yes	Fit or 20 SEER (late '22)
			Cold Climate HP (yes/no)			Yes	All-climate HP models only.
			request for fan2			Yes	All-climate HP and 5-ton enhanced models only
			fan2 motor current			Yes	All-climate HP and 5-ton enhanced models only
			target fan2 speed			Yes	All-climate HP and 5-ton enhanced models only
			current fan2 speed			Yes	All-climate HP and 5-ton enhanced models only
			OD EEV Opening (%)			Yes	Fit or 20 SEER (late '22)
			liquid EEV Opening (%)			Yes	All-climate HP and 5-ton enhanced models only
			powerful heating status			Yes	R32 inverter models only
			IP coil freeze protection			Yes	Fit or 20 SEER (late '22)
			drain pan heater			Yes	Fit or 20 SEER (late '22)
			preheat			Yes	Fit (late '22)
			preheat output (W)			Yes	Fit or 20 SEER (late '22)
			operation mode			Yes	Fit or 20 SEER (late '22)
			current critical error			Yes	
			current minor error			Yes	
			current heat demand			Yes	
			current heat demand			Yes	

		requested heat demand				Yes	
		electric heat stages				Yes	R32 EEV air handlers only
		current indoor CFM				Yes	
		current indoor fan demand				Yes	
		requested indoor fan demand				Yes	
		requested hum demand				Yes	
		refrigerant type				Yes	EEV air handlers only
		refrigerant leak detected				Yes	R32 EEV air handlers only
		indoor superheat				Yes	EEV air handlers only, if cooling and data valid
		fan runtime				Yes	EEV air handlers only
		liquid temperature				Yes	EEV air handlers only
		suction temperature				Yes	EEV air handlers only
		pressure sensor				Yes	EEV air handlers only, removed for R32 units
		aux alarm status				Yes	EEV air handlers only, removed for R32 units
		operation mode				Yes	Hidden for DTA furnace adaptors
		current critical error				Yes	
		current minor error				Yes	
		current heat demand				Yes	
		requested heat demand				Yes	
		current cool demand				Yes	Hidden for DTA furnace adaptors
		requested cool demand				Yes	Hidden for DTA furnace adaptors
		current indoor CFM				Yes	Hidden for DTA furnace adaptors
		current indoor fan demand				Yes	Hidden for DTA furnace adaptors
		requested indoor fan demand				Yes	Hidden for DTA furnace adaptors
		requested hum demand				Yes	Hidden for DTA furnace adaptors
		requested dehum demand				Yes	Hidden for DTA furnace adaptors
		current critical error				Yes	
		current minor error				Yes	
		refrigerant type				Yes	R32 EEVs only
		indoor superheat				Yes	EEV air handlers only, if cooling and data valid; value is 32°F high;
		liquid temperature				Yes	
		suction temperature				Yes	
		pressure sensor				Yes	
		min/max setpoints	50°F to 90°F in 1°F increments (10°C to 32°C in 0.5°C steps)			50°F to 90°F (10°C to 32°C)	
	cool/heat	deadband / overcool	Temperature setpoint dead band: 2°F to 9°F in 1°F steps (0°C to 5°C in 0.5°C steps)			4°F / 2°C	If system capabilities include heating and cooling
			Overcooling allowed to dehumidify: 0, 1, 2, or 3°F (0, 0.5, 1, or 1.5°C)			0°F / 0°C	If system capabilities include cooling
	quiet mode (planned for v3.7 release)	cooling boost mode	on, off				16-18 and newer 20 SEER inverters only
			outdoor activation temperature	Always ON, 70F, 75F, 80F, 85F, 90F, 95F, 100F, 105F			16-18 and newer 20 SEER inverters only, when boost mode on
5. Preferences		heating boost mode	on, off				Fit HP from May 2021
		powerful heating	on, off				R32 inverter HPs only
		disable humidification	(checkbox)			unchecked	Only affects systems with humidification
		enable tight setpoint control	(checkbox)			unchecked	R32 equipment only, with v3.7 release
		use quiet mode	(checkbox)			disabled	Side discharge units only
	(event 1 name)		time	(time selection in 15 min increments)	10pm		Side discharge units only
			label	(text entry)	"night time"		Side discharge units only
			Sound suppression level	Off Quiet (1) Quieter (2) Quietest (3)	Quietest (3)		Side discharge units only
			Capacity priority	(checkbox)	disabled		Side discharge units only
			time	(time selection in 15 min increments)	7am		Side discharge units only
			label	(text entry)	"day time"		Side discharge units only
			Sound suppression level	Off Quiet (1) Quieter (2) Quietest (3)	Off		Side discharge units only
			Capacity priority	(checkbox)	disabled		Side discharge units only
			time	(time selection in 15 min increments)	0		Side discharge units only
			label	(text entry)	NULL		Side discharge units only
	(event 2 name)		Sound suppression level	Off Quiet (1) Quieter (2) Quietest (3)	Level 1		Side discharge units only
			Capacity priority	(checkbox)	disabled		Side discharge units only
			(similar to event 3)	(similar to event 3)	(none)		Side discharge units only
			(checkbox)	checked			Side discharge units only
					not available		
	house size	500 to 10,000 sf in 100 sqft steps					
		vertical rise	Same level Outdoor lower				Inverter AC/HP (removed in late 2022)
		name	(text entry)				
		phone	(text entry)				
		email	(text entry)				
	reminders	website	(text entry)				
		media filter	off, 1, 2, 3, 4, 6, or 12 months			off	If media filter
		HEPA filter	off, 1, 2, 3, 4, 6, or 12 months			off	If HEPA filter
		Electronic filter	off, 1, 2, 3, 4, 6, or 12 months			off	If Electronic filter
		UV bulbs	off, 6, 12, 18, or 24 months			off	If UV bulbs
	service reminder	dehumidification filter	off, 1, 3, 6, or 12 months			off	If dehumidifier
		humidifier pad	off, 3, 6, or 12 months			off	If humidifier
		service reminder	off, 1, 2, 3, 4, 6, or 12 months			off	If service reminder setup